

350i

450i

550i

TRANSMIG MULTI PROCESS WELDING INVERTER



A-10625

Operating Manual

Revision: AE
Operating Features:

Issue Date: May 7, 2013

Manual No.: 0-5205





WE APPRECIATE YOUR BUSINESS!

Congratulations on your new Cigweld product. We are proud to have you as our customer and will strive to provide you with the best service and reliability in the industry. This product is backed by our extensive warranty and world-wide service network. To locate your nearest distributor or accredited service provider call +1300 654 674, or visit us on the web at **www.cigweld.com.au**

This Operating Manual has been designed to instruct you on the correct use and operation of your CIGWELD product. Your satisfaction with this product and its safe operation is our ultimate concern. Therefore please take the time to read the entire manual, especially the Safety Precautions. They will help you to avoid potential hazards that may exist when working with this product.

YOU ARE IN GOOD COMPANY!

The Brand of Choice for Contractors and Fabricators Worldwide.

CIGWELD is the Market Leading Brand of Arc Welding Products for Victor Technologies. We are a mainline supplier to major welding industry sectors in the Asia Pacific and emerging global markets including; Manufacturing, Construction, Mining, Automotive, Engineering, Rural and DIY.

We distinguish ourselves from our competition through market-leading, dependable products that have stood the test of time. We pride ourselves on technical innovation, competitive prices, excellent delivery, superior customer service and technical support, together with excellence in sales and marketing expertise.

Above all, we are committed to develop technologically advanced products to achieve a safer working environment for industry operators.



WARNINGS

Read and understand this entire Manual and your employer's safety practices before installing, operating, or servicing the equipment.

While the information contained in this Manual represents the Manufacturer's best judgement, the Manufacturer assumes no liability for its use.

Welding Power Supply
Operating Manual Number 0-5205 for:

| | |
|--|----------------------|
| TRANSMIG 350i Plant | Part Number W1005350 |
| TRANSMIG 350i Power Source (packed) | Part Number W1005352 |
| TRANSMIG 450i Plant with 4RT wirefeeder | Part Number W1005450 |
| TRANSMIG 450i Pro Plant with VAF4 wirefeeder | Part Number W1005451 |
| TRANSMIG 450i Power Source (packed) | Part Number W1005452 |
| TRANSMIG 550i Plant | Part Number W1005550 |
| TRANSMIG 550i Power Source (packed) | Part Number W1005552 |

Published by:
CIGWELD Pty Ltd
71 Gower Street
Preston, Victoria, Australia, 3072

www.cigweld.com.au

Copyright 2011, 2012, 2013 by
CIGWELD

All rights reserved.

A Reproduction of this work, in whole or in part, without written permission of the publisher is prohibited.

The publisher does not assume and hereby disclaims any liability to any party for any loss or damage caused by any error or omission in this Manual, whether such error results from negligence, accident, or any other cause.

Publication Date: November 21, 2011
Revision AE Date: May 7, 2013

Record the following information for Warranty purposes:

Where Purchased: _____

Purchase Date: _____

Equipment Serial #: _____

TABLE OF CONTENTS

SECTION 1:

ARC WELDING SAFETY INSTRUCTIONS AND WARNINGS 1-1

| | | |
|------|---------------------------------|-----|
| 1.01 | Arc Welding Hazards..... | 1-1 |
| 1.02 | Principal Safety Standards..... | 1-5 |
| 1.03 | Declaration of Conformity..... | 1-6 |

SECTION 2:

INTRODUCTION 2-1

| | | |
|------|---|-----|
| 2.01 | How To Use This Manual | 2-1 |
| 2.02 | Equipment Identification | 2-1 |
| 2.03 | Receipt Of Equipment | 2-1 |
| 2.04 | Symbol Chart..... | 2-2 |
| 2.05 | Description | 2-3 |
| 2.06 | User Responsibility..... | 2-3 |
| 2.07 | Transporting Methods..... | 2-3 |
| 2.08 | Packaged Items | 2-4 |
| 2.09 | Duty Cycle..... | 2-5 |
| 2.10 | Specifications | 2-6 |
| 2.11 | Gouging Specifications (Transmig 550i only) | 2-7 |
| 2.12 | Optional Accessories | 2-8 |

SECTION 3:

INSTALLATION, OPERATION AND SETUP 3-1

| | | |
|------|---|------|
| 3.01 | Environment | 3-1 |
| 3.02 | Location..... | 3-1 |
| 3.03 | Ventilation..... | 3-1 |
| 3.04 | Mains Supply Voltage Requirements | 3-1 |
| 3.05 | Electromagnetic Compatibility | 3-1 |
| 3.06 | Transmig 350i, 450i, 550i Power Source Controls, Indicators and Features .. | 3-3 |
| 3.07 | Shielding Gas Regulator Operating Instructions | 3-15 |
| 3.08 | Setup for MIG (GMAW) Welding with Gas Shielded Mig Wire | 3-17 |
| 3.09 | Setup for MIG (GMAW) Welding with Gasless Mig Wire | 3-20 |
| 3.10 | Setup for TIG (GTAW) Welding With Gas Shielding | 3-22 |
| 3.11 | Setup for STICK (MMAW) Welding | 3-23 |
| 3.12 | Setup for GOUGING (Transmig 550i only) | 3-24 |

SECTION 4:

BASIC WELDING GUIDE 4-1

| | | |
|------|---|------|
| 4.01 | MIG (GMAW/FCAW) Basic Welding Technique | 4-1 |
| 4.02 | MIG (GMAW/FCAW) Welding Troubleshooting | 4-7 |
| 4.03 | Stick (MMAW) Basic Welding Technique | 4-10 |
| 4.04 | Stick (MMAW) Welding Troubleshooting..... | 4-21 |
| 4.05 | TIG (GTAW) Basic Welding Technique | 4-23 |
| 4.06 | TIG (GTAW) Welding Problems..... | 4-25 |

TABLE OF CONTENTS

| | | |
|---|---|------------|
| SECTION 5: | | |
| POWER SOURCE PROBLEMS AND ROUTINE SERVICE REQUIREMENTS | | 5-1 |
| 5.01 | Power Source / Wirefeeder Problems | 5-1 |
| 5.02 | Routine Service and Calibration Requirements..... | 5-2 |
| 5.03 | Cleaning the Welding Power Source | 5-4 |
| 5.04 | Cleaning the Feed Rolls..... | 5-4 |
| SECTION 6: | | |
| KEY SPARE PARTS..... | | 6-1 |
| 6.01 | Power Source | 6-1 |
| SECTION 7: | | |
| VOLT/AMPERE CURVES | | 7-1 |
| 7.01 | Volt/Amp Curves..... | 7-1 |
| SECTION 8: CIRCUIT DIAGRAM | | 8-1 |
| 8.01 | Circuit Diagram..... | 8-1 |
| CIGWELD - LIMITED WARRANTY TERMS | | |
| TERMS OF WARRANTY – JULY 2011 | | |
| WARRANTY SCHEDULE – JULY 2011 | | |
| GLOBAL CUSTOMER SERVICE CONTACT INFORMATION | | |

SECTION 1:

ARC WELDING SAFETY INSTRUCTIONS AND WARNINGS



WARNING

PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS KEEP AWAY UNTIL CONSULTING YOUR DOCTOR. DO NOT LOSE THESE INSTRUCTIONS. READ OPERATING/INSTRUCTION MANUAL BEFORE INSTALLING, OPERATING OR SERVICING THIS EQUIPMENT.

Welding products and welding processes can cause serious injury or death, or damage to other equipment or property, if the operator does not strictly observe all safety rules and take precautionary actions.

Safe practices have developed from past experience in the use of welding and cutting. These practices must be learned through study and training before using this equipment. Some of these practices apply to equipment connected to power lines; other practices apply to engine driven equipment. Anyone not having extensive training in welding and cutting practices should not attempt to weld.

Safe practices are outlined in the Australian Standard AS1674.2-2007 entitled: Safety in welding and allied processes Part 2: Electrical. This publication and other guides to what you should learn before operating this equipment are listed at the end of these safety precautions. **HAVE ALL INSTALLATION, OPERATION, MAINTENANCE, AND REPAIR WORK PERFORMED ONLY BY QUALIFIED PEOPLE.**

1.01 ARC WELDING HAZARDS




WARNING

ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

1. Do not touch live electrical parts.
2. Wear dry, hole-free insulating gloves and body protection.
3. Insulate yourself from work and ground using dry insulating mats or covers.
4. Disconnect input power or stop engine before installing or servicing this equipment. Lock input power disconnect switch open, or remove line fuses so power cannot be turned on accidentally.
5. Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.
6. Turn off all equipment when not in use. Disconnect power to equipment if it will be left unattended or out of service.
7. Use fully insulated electrode holders. Never dip holder in water to cool it or lay it down on the ground or the work surface. Do not touch holders connected to two welding machines at the same time or touch other people with the holder or electrode.
8. Do not use worn, damaged, undersized, or poorly spliced cables.
9. Do not wrap cables around your body.
10. Ground the workpiece to a good electrical (earth) ground.
11. Do not touch electrode while in contact with the work (ground) circuit.
12. Use only well-maintained equipment. Repair or replace damaged parts at once.
13. In confined spaces or damp locations, do not use a welder with AC output unless it is equipped with a voltage reducer. Use equipment with DC output.
14. Wear a safety harness to prevent falling if working above floor level.
15. Keep all panels and covers securely in place.


WARNING

ARC RAYS can burn eyes and skin; NOISE can damage hearing.

Arc rays from the welding process produce intense heat and strong ultraviolet rays that can burn eyes and skin. Noise from some processes can damage hearing.

1. Use a Welding Helmet or Welding Faceshield fitted with a proper shade of filter (see ANSI Z49.1 and AS 1674 listed in Safety Standards) to protect your face and eyes when welding or watching.
2. Wear approved safety glasses. Side shields recommended.
3. Use protective screens or barriers to protect others from flash and glare; warn others not to watch the arc.
4. Wear protective clothing made from durable, flame-resistant material (wool and leather) and foot protection.
5. Use approved ear plugs or ear muffs if noise level is high.
6. Never wear contact lenses while welding.

| Recommended Protective Filters for Electric Welding | | |
|---|--|-----------------------------------|
| Description of Process | Approximate Range of Welding Current in Amps | Minimum Shade Number of Filter(s) |
| Manual Metal Arc Welding - covered electrodes (MMAW) | Less than or equal to 100 | 8 |
| | 100 to 200 | 10 |
| | 200 to 300 | 11 |
| | 300 to 400 | 12 |
| | Greater than 400 | 13 |
| Gas Metal Arc Welding (GMAW) (MIG) other than Aluminium and Stainless Steel | Less than or equal to 150 | 10 |
| | 150 to 250 | 11 |
| | 250 to 300 | 12 |
| | 300 to 400 | 13 |
| | Greater than 400 | 14 |
| Gas Metal Arc Welding (GMAW) (MIG) Aluminium and Stainless Steel | Less than or equal to 250 | 12 |
| | 250 to 350 | 13 |
| Gas Tungsten Arc Welding (GTAW) (TIG) | Less than or equal to 100 | 10 |
| | 100 to 200 | 11 |
| | 200 to 250 | 12 |
| | 250 to 350 | 13 |
| | Greater than 350 | 14 |
| Flux-cored Arc Welding (FCAW) -with or without shielding gas. | Less than or equal to 300 | 11 |
| | 300 to 400 | 12 |
| | 400 to 500 | 13 |
| | Greater than 500 | 14 |
| Air - Arc Gouging | Less than or equal to 400 | 12 |
| Plasma - Arc Cutting | 50 to 100 | 10 |
| | 100 to 400 | 12 |
| | 400 to 800 | 14 |
| Plasma - Arc Spraying | — | 15 |
| Plasma - Arc Welding | Less than or equal to 20 | 8 |
| | 20 to 100 | 10 |
| | 100 to 400 | 12 |
| | 400 to 800 | 14 |
| Submerged - Arc Welding | — | 2(5) |
| Resistance Welding | — | Safety Spectacles or eye shield |

Refer to standard AS/NZS 1338.1:1992 for comprehensive information regarding the above table.




WARNING

FUMES AND GASES can be hazardous to your health.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

1. Keep your head out of the fumes. Do not breathe the fumes.
2. If inside, ventilate the area and/or use exhaust at the arc to remove welding fumes and gases.
3. If ventilation is poor, use an approved air-supplied respirator.
4. Read the Material Safety Data Sheets (MSDSs) and the manufacturer's instruction for metals, consumables, coatings, and cleaners.
5. Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Shielding gases used for welding can displace air causing injury or death. Be sure the breathing air is safe.
6. Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapours to form highly toxic and irritating gases.
7. Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and if necessary, while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



WARNING

WELDING can cause fire or explosion.

Sparks and spatter fly off from the welding arc. The flying sparks and hot metal, weld spatter, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode or welding wire to metal objects can cause sparks, overheating, or fire.

1. Protect yourself and others from flying sparks and hot metal.
2. Do not weld where flying sparks can strike flammable material.

3. Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
4. Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
5. Watch for fire, and keep a fire extinguisher nearby.
6. Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
7. Do not weld on closed containers such as tanks or drums.
8. Connect work cable to the work as close to the welding area as practical to prevent welding current from travelling long, possibly unknown paths and causing electric shock and fire hazards.
9. Do not use welder to thaw frozen pipes.
10. Remove stick electrode from holder or cut off welding wire at contact tip when not in use.



WARNING

FLYING SPARKS AND HOT METAL can cause injury.

Chipping and grinding cause flying metal. As welds cool, they can throw off slag.

1. Wear approved face shield or safety goggles. Side shields recommended.
2. Wear proper body protection to protect skin.



WARNING

CYLINDERS can explode if damaged.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

1. Protect compressed gas cylinders from excessive heat, mechanical shocks, and arcs.
2. Install and secure cylinders in an upright position by chaining them to a stationary support or equipment cylinder rack to prevent falling or tipping.
3. Keep cylinders away from any welding or other electrical circuits.
4. Never allow a welding electrode to touch any cylinder.

TRANSMIG 350i, 450i, 550i

5. Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
6. Turn face away from valve outlet when opening cylinder valve.
7. Keep protective cap in place over valve except when cylinder is in use or connected for use.
8. Read and follow instructions on compressed gas cylinders, associated equipment, and CGA publication P-1 listed in Safety Standards.



WARNING

MOVING PARTS can cause injury.

Moving parts, such as fans, rotors, and belts can cut fingers and hands and catch loose clothing.

1. Keep all doors, panels, covers, and guards closed and securely in place.
2. Stop engine before installing or connecting unit.
3. Have only qualified people remove guards or covers for maintenance and troubleshooting as necessary.
4. To prevent accidental starting during servicing, disconnect negative (-) battery cable from battery.
5. Keep hands, hair, loose clothing, and tools away from moving parts.
6. Reinstall panels or guards and close doors when servicing is finished and before starting engine.



WARNING

This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety code Sec. 25249.5 et seq.)

NOTE

Considerations About Welding And The Effects of Low Frequency Electric and Magnetic Fields

The following is a quotation from the General Conclusions Section of the U.S. Congress, Office of Technology Assessment, Biological Effects of Power Frequency Electric & Magnetic Fields - Background Paper, OTA-BP-E-63 (Washington, DC: U.S. Government Printing Office, May 1989): "...there is now

a very large volume of scientific findings based on experiments at the cellular level and from studies with animals and people which clearly establish that low frequency magnetic fields and interact with, and produce changes in, biological systems. While most of this work is of very high quality, the results are complex. Current scientific understanding does not yet allow us to interpret the evidence in a single coherent framework. Even more frustrating, it does not yet allow us to draw definite conclusions about questions of possible risk or to offer clear science-based advice on strategies to minimize or avoid potential risks."

To reduce magnetic fields in the workplace, use the following procedures.

1. Keep cables close together by twisting or taping them.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cable around the body.
4. Keep welding power source and cables as far away from body as practical.



ABOUT PACEMAKERS:

The above procedures are among those also normally recommended for pacemaker wearers. Consult your doctor for complete information.

1.02 PRINCIPAL SAFETY STANDARDS

Safety in Welding and Cutting, ANSI Standard Z49.1, from American Welding Society, 550 N.W. LeJeune Rd., Miami, FL 33126.

Safety and Health Standards, OSHA 29 CFR 1910, from Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402.

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers That Have Held Hazardous Substances, American Welding Society Standard AWS F4.1, from American Welding Society, 550 N.W. LeJeune Rd., Miami, FL 33126.

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202.

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3.

Safe Practices for Occupation and Educational Eye and Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 1430 Broadway, New York, NY 10018.

Cutting and Welding Processes, NFPA Standard 51B, from National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

Safety in welding and allied processes Part 1: Fire Precautions, AS 1674.1-1997 from SAI Global Limited, www.saiglobal.com.

Safety in welding and allied processes Part 2: Electrical, AS 1674.2-2007 from SAI Global Limited, www.saiglobal.com.

Filters for eye protectors - Filters for protection against radiation generated in welding and allied operations AS/NZS 1338.1:1992 from SAI Global Limited, www.saiglobal.com.

1.03 DECLARATION OF CONFORMITY

Manufacturer and Merchandiser of Quality Consumables and Equipment :
Address:

CIGWELD
71 Gower St, Preston
Victoria 3072
Australia



Description of equipment: Welding Equipment: TRANSMIG 350i, 450i, 550i MULTI PROCESS INVERTER Power Source and associated accessories.

- * Serial numbers are unique with each individual piece of equipment and details description, parts used to manufacture a unit and date of manufacture.
- * The equipment conforms to all applicable aspects and regulations of the 'Low Voltage Directive' (Directive 73/23/EU, as recently changed in Directive 93/68/EU and to the National legislation for the enforcement of the Directive.

National Standard and Technical Specifications

The product is designed and manufactured to a number of standards and technical requirements among them are:

- * AS 60974.10/IEC 60974-10 EMC Directive applicable to arc welding equipment - generic emissions and regulations.
- * AS 60974.1/IEC 60974-1 applicable to welding equipment and associated accessories.
- * AS 1674 Safety in welding and allied processes
- * Extensive product design verification is conducted at the manufacturing facility as part of the routine design and manufacturing process, to ensure the product is safe and performs as specified. Rigorous testing is incorporated into the manufacturing process to ensure the manufactured product meets or exceeds all design specifications.

CIGWELD has been manufacturing and merchandising an extensive equipment range with superior performance, ultra safe operation and world class quality for more than 30 years and will continue to achieve excellence.

SECTION 2: INTRODUCTION

2.01 How To Use This Manual

To ensure safe operation, read the entire manual, including the chapter on safety instructions and warnings.

Throughout this manual, the words WARNING, CAUTION, and NOTE may appear. Pay particular attention to the information provided under these headings. These special annotations are easily recognized as follows:



WARNING

A WARNING gives information regarding possible personal injury.



CAUTION

A CAUTION refers to possible equipment damage.

NOTE

A NOTE offers helpful information concerning certain operating procedures.

Additional copies of this manual may be purchased by contacting Cigweld at the address and phone number for your location listed in the inside back cover of this manual. Include the Owner's Manual number and equipment identification numbers.

2.02 Equipment Identification

The unit's identification number (specification or part number), model, and serial number usually appear on a nameplate attached to the control panel. In some cases, the nameplate may be attached to the rear panel. Equipment which does not have a control panel such as gun and cable assemblies is identified only by the specification or part number printed on the shipping container. Record these numbers on the bottom of page i for future reference.

2.03 Receipt Of Equipment

When you receive the equipment, check it against the invoice to make sure it is complete and inspect the equipment for possible damage due to shipping. If there is any damage, notify the carrier immediately to file a claim. Furnish complete information concerning damage claims or shipping errors to the location in your area listed in the inside back cover of this manual.

Include all equipment identification numbers as described above along with a full description of the parts in error.

Move the equipment to the installation site before un-crating the unit. Use care to avoid damaging the equipment when using bars, hammers, etc., to uncrate the unit.

2.04 Symbol Chart

Note that only some of these symbols will appear on your model.

| | | | | | |
|--|-----------------------------------|--|--|---|--|
| | On | | Single Phase | | Wire Feed Function |
| | Off | | Three Phase | | Wire Feed Towards Workpiece With Output Voltage Off. |
| | Dangerous Voltage | | Three Phase Static Frequency Converter-Transformer-Rectifier | | Welding Gun |
| | Increase/Decrease | | Remote | | Purging Of Gas |
| | Circuit Breaker | | Duty Cycle | | Continuous Weld Mode |
| | AC Auxiliary Power | | Percentage | | Spot Weld Mode |
| | Fuse | | Panel/Local | | Spot Time |
| | Amperage | | Shielded Metal Arc Welding (SMAW) | | Preflow Time |
| | Voltage | | Gas Metal Arc Welding (GMAW) | | Postflow Time |
| | Hertz (cycles/sec) | | Gas Tungsten Arc Welding (GTAW) | 2 Step Trigger Operation Press to initiate wirefeed and welding, release to stop. | |
| | Frequency | | Air Carbon Arc Cutting (CAC-A) | 4 Step Trigger Operation Press and hold for preflow, release to start arc. Press to stop arc, and hold for preflow. | |
| | Negative | | Constant Current | | Burnback Time |
| | Positive | | Constant Voltage Or Constant Potential | | Disturbance In Ground System |
| | Direct Current (DC) | | High Temperature | | Inches Per Minute |
| | Protective Earth (Ground) | | Fault Indication | | Meters Per Minute |
| | Line | | Arc Force | | |
| | Line Connection | | Touch Start (GTAW) | | |
| | Auxiliary Power | | Variable Inductance | | |
| | Receptacle Rating-Auxiliary Power | | Voltage Input | | |

Art# A-04937

2.05 Description

The Cigweld Transmig 350i, 450i and 550i are three phase multi process welding inverters that are capable of performing GMAW/FCAW (MIG), MMAW (Stick) and GTAW (Lift TIG) welding processes. The unit is equipped with an integrated voltage reduction device (VRD applicable in stick mode only), digital voltage and amperage meters, and a host of other features in order to fully satisfy the broad operating needs of the modern welding professional. The unit is also fully compliant to Australian Standard AS 60974.1 and IEC 60974.1.

The Transmig 350i, 450i and 550i provide excellent welding performance across a broad range of applications when used with the correct welding consumables and procedures. The following instructions detail how to correctly and safely set up the machine and give guidelines on gaining the best efficiency and quality from the Power Source. Please read these instructions thoroughly before using the unit.

2.06 User Responsibility

This equipment will perform as per the information contained herein when installed, operated, maintained and repaired in accordance with the instructions provided. This equipment must be checked periodically. Defective equipment (including welding leads) should not be used. Parts that are broken, missing, plainly worn, distorted or contaminated, should be replaced immediately. Should such repairs or replacements become necessary, it is recommended that such repairs be carried out by appropriately qualified persons approved by CIGWELD. Advice in this regard can be obtained by contacting an Accredited CIGWELD Distributor.

This equipment or any of its parts should not be altered from standard specification without prior written approval of CIGWELD. The user of this equipment shall have the sole responsibility for any malfunction which results from improper use or unauthorized modification from standard specification, faulty maintenance, damage or improper repair by anyone other than appropriately qualified persons approved by CIGWELD.

2.07 Transporting Methods

This unit is equipped with a handle for carrying purposes.



WARNING

ELECTRIC SHOCK can kill. DO NOT TOUCH live electrical parts. Disconnect input power conductors from de-energized supply line before moving the welding power source.



WARNING

FALLING EQUIPMENT can cause serious personal injury and equipment damage.

Lift unit with handle or lifting lug on top of case.

Use handcart or similar device of adequate capacity.

If using a fork lift vehicle, place and secure unit on a proper skid before transporting.

2.08 Packaged Items

Transmig 350i Plant (Part No. W1005350)

- Transmig 350i Inverter Power Source
- Transmig 4RT wirefeeder with 8m interconnection lead fitted
- Tweco Professional No.4 Mig Torch
- Comet Professional Argon regulator/flowmeter
- Feed roll: 0.9/1.2mm V groove (fitted)
- Electrode holder with 5m lead
- Work clamp with 5m lead
- Trolley
- Operating Manual

Transmig 350i Power Source (Part No. W1005352)

- Transmig 350i inverter Power Source
- Operating Manual

Transmig 450i Plant (Part No. W1005450)

- Transmig 450i Inverter Power Source
- Transmig 4RT wirefeeder with 8m interconnection lead fitted
- Tweco Professional Supra XT Mig Torch
- Comet Professional Argon regulator/flowmeter
- Feed roll: 0.9/1.2mm V groove (fitted)
- Electrode holder with 8m lead
- Work clamp with 8m lead
- Trolley
- Operating Manual

Transmig 450i Pro Plant (Part No. W1005451)

- Transmig 450i Inverter Power Source
- Transmig VAF-4 wirefeeder with 8m interconnection lead fitted
- Tweco Professional Supra XT Mig Torch
- Comet Professional Argon regulator/flowmeter
- Feed roll: 0.9/1.2mm V groove (fitted)
- Electrode holder with 8m lead
- Work clamp with 8m lead
- Trolley
- Operating Manual

Transmig 450i Power Source (Part No. W1005452)

- Transmig 450i inverter Power Source
- Operating Manual

Transmig 550i Plant (Part No. W1005550)

- Transmig 550i Inverter Power Source
- Transmig VA4000 wirefeeder with 15m interconnection lead
- Tweco Professional Supra XT Mig Torch
- Comet Professional Argon regulator/flowmeter
- Feed roll: 1.3/1.6mm V groove (fitted)
- Electrode holder with 8m lead
- Work clamp with 8m lead
- Trolley
- Operating Manual

Transmig 550i Power Source (Part No. W1005552)

- Transmig 550i inverter Power Source
- Operating Manual

2.09 Duty Cycle

The rated duty cycle of a Welding Power Source, is a statement of the time it may be operated at its rated welding current output without exceeding the temperature limits of the insulation of the component parts. To explain the 10 minute duty cycle period the following example is used. Suppose a Welding Power Source is designed to operate at a 60% duty cycle, 550 amperes at 41.5 volts. This means that it has been designed and built to provide the rated amperage (550A) for 6 minutes, i.e. arc welding time, out of every 10 minute period (60% of 10 minutes is 6minutes). During the other 4minutes of the 10 minute period the Welding Power Source must idle and allowed to cool. The thermal cut out will operate if the duty cycle is exceeded.




Figure 2-1: Transmig 350i, 450i, 550i Duty Cycle

2.10 Specifications

| Description | TRANSMIG 350i | TRANSMIG 450i | TRANSMIG 550i |
|--|---|---|--|
| Plant Part Number | W1005350 | W1005450 W1005451 | W1005550 |
| Power Source (Packed)Part Number | W1005352 | W1005452 | W1005552 |
| Power Source Mass | 72 kg | 72 kg | 72 kg |
| Power Source Dimensions | H 580mm x W 350mm x D 640mm | | |
| Cooling | Fan Cooled | | |
| Welder Type | Multi Process Inverter Power Source | | |
| Applicable Standards | AS 60974.1-2006 / IEC 60974-1 | | |
| Number of Phases | 3 | | |
| Nominal Supply Voltage | 415V +/- 15% | | |
| Nominal Supply Frequency | 50/60Hz | | |
| Welding Current Range (MIG Mode) | 40 – 350A | 40 – 450A | 40 – 550A |
| Effective Input Current (I _{1eff}) (note1) | 18A | 25A | 32A |
| Maximum Input Current (I _{1max}) | 25A | 35A | 47A |
| Three Phase Generator Requirement (note 3) | 18kVA | 25kVA | 35kVA |
| MIG (GMAW) Welding Output, 40°C, 10 min. | 350A @ 60%, 31.5V 270A @ 100%, 27.5V | 450A @ 60%, 36.5V 350A @ 100%, 31.5V | 550A @ 60%, 41.5V 420A @ 100%, 35.0V |
| STICK (MMAW) Welding Output, 40°C, 10 min. | 350A @ 60%, 34.0V 270A @ 100%, 30.8V | 450A @ 60%, 38.0V 350A @ 100%, 34.0V | 550A @ 60%, 42.0V 420A @ 100%, 36.8V |
| TIG (GTAW) Welding Output, 40°C, 10 min. | 350A @ 60%, 24.0V 270A @ 100%, 20.8V | 450A @ 60%, 28.0V 350A @ 100%, 24.0V | 550A @ 60%, 32.0V 420A @ 100%, 26.8V |
| Gouging (CAG) Welding Output, 40°C, 3 min. Note: Gouging is specified over a 3 minute duty cycle period only. | Not Available | Not Available | 6.5mm Carbon 400A@63% 8.0mm Carbon 450A@54% 9.5mm Carbon 550A@35% |
| Open circuit voltage (VRD inactive) | 84V | 84V | 84V |
| Protection Class | IP23S | IP23S | IP23S |

Table 2-1: Power Source Specification

Note 1: The Effective Input Current should be used for the determination of cable size & supply requirements.

Note 2: Motor start fuses or thermal circuit breakers are recommended for this application. Check local requirements for your situation in this regard.

Note 3: Generator Requirements at the Maximum Output Duty Cycle.

NOTE

Due to variations that can occur in manufactured products, claimed performance, voltages, ratings, all capacities, measurements, dimensions and weights quoted are approximate only. Achievable capacities and ratings in use and operation will depend upon correct installation, use, applications, maintenance and service. In the interest of continuous improvement, CIGWELD Pty, Ltd reserves the right to change the specifications or design of any of its products without prior notice.

2.11 Gouging Specifications (Transmig 550i only)

Gouging is a process where a copper coated carbon electrode is used to rapidly remove material from the workpiece.

The arc voltage is much higher during Gouging, than in Stick, or Mig welding. This means, that for the same output current, we have much higher arc volts during Gouging, and therefore much higher output power. It is because of this extra output power, that we need to rate the power source differently for gouging, than we do for welding.

Also as we are drawing a much higher output power from the power source during Gouging, in order to keep the power source's internal temperatures within acceptable limits, the Duty Cycle for Gouging is specified over a 3 minute duty cycle period, instead of the normal 10 minute duty cycle period specified for the welding processes.

Refer to Section 3.12 for how to set up for gouging.

Carbon electrodes have a range of specified operating current. Here are the normal sizes that would be in use with a power source of this size, and the power source capability when used with these carbon electrode sizes

| Electrode Size | Amps | Duty Cycle |
|----------------|------|------------|
| 6.5mm | 300A | 90% |
| | 400A | 63% |
| 8.0mm | 350A | 70% |
| | 450A | 54% |
| 9.5mm | 450A | 50% |
| | 550A | 35% |

Table 2-2: Electrode Size




Figure 2-2: Gouging Current (AMPS)

TRANSMIG 350i, 450i, 550i

As an example, if we were Gouging with an 8mm electrode at 400A, we can see from the graph that we can expect 400A at 57% duty cycle. For a 3 minute duty cycle period, this means our arc time is 57% of 3 minutes, which is 1 minute & 40 seconds, during the other 1 minute & 20 seconds the machine must be allowed to cool.

NOTE

Gouging is specified for a 3 minute duty cycle period only.

2.12 Optional Accessories

| Part Number | Description |
|-------------|--|
| 717201 | TWECO #4 Mig Torch, 3.6 metre Tweco connection |
| 717335 | TWECO #4 Mig Torch, 4.5 metre Tweco connection |
| SE4004M16 | TWECO Supra XT Mig Torch (4.0M) Tweco connection |
| 717211 | TWECO #5 torch, 3.6 metre Tweco connection |
| 717212 | TWECO #5 torch, 4.5 metre Tweco connection |
| W4015500 | Heavy Duty Transmig Trolley with inbuilt cylinder carrier |
| W4015600 | Heavy Duty Transmig Roll Cage |
| W4014602 | Tig Torch 26V, Flex neck, 4m lead, gas valve, 3m gas hose, 10 pin connector and accessory kit. |
| 706954 | TRANSMIG VA4000 wirefeeder, 19 pin, 110VAC |
| 706965 | TRANSMIG VAF-4 wirefeeder, 19 pin, 110VAC |
| WSPLIER | MIG Pliers |
| 646265 | Weld measurement gauge |
| W7005358 | 10 Pin Control Plug |
| 7977877 | 19 Pin Control Plug |

Table 2-3: Optional Accessories

SECTION 3: INSTALLATION, OPERATION AND SETUP

3.01 Environment

These units are designed for use in environments with increased hazard of electric shock as outlined in AS 60974.1 and AS 1674.2.

- A. Examples of environments with increased hazard of electric shock are:
1. In locations in which freedom of movement is restricted, so that the operator is forced to perform the work in a cramped (kneeling, sitting or lying) position with physical contact with conductive parts;
 2. In locations which are fully or partially limited by conductive elements, and in which there is a high risk of unavoidable or accidental contact by the operator, or
 3. In wet or damp hot locations where humidity or perspiration considerably reduces the skin resistance of the human body and the insulation properties of accessories
- B. Environments with increased hazard of electric shock do not include places where electrically conductive parts in the near vicinity of the operator, which can cause increased hazard, have been insulated.

3.02 Location

Be sure to locate the welder according to the following guidelines:

- A. In areas, free from moisture and dust.
- B. Ambient temperature between 0° C to 40° C.
- C. In areas, free from oil, steam and corrosive gases.
- D. In areas, not subjected to abnormal vibration or shock.
- E. In areas, not exposed to direct sunlight or rain.
- F. Place at a distance of 300mm or more from walls or similar that could restrict natural air flow for cooling.
- G. The enclosure design of this power source meets the requirements of IP23S as outlined in AS60529. This provides adequate protection against solid objects (greater than 12mm), and direct protection from vertical drops. Under no circumstances should the unit be operated or connected in a micro environment that will exceed the stated

conditions. For further information please refer to AS 60529.

- H. Precautions must be taken against the power source toppling over. The power source must be located on a suitable horizontal surface in the upright position when in use.

3.03 Ventilation

Since the inhalation of welding fumes can be harmful, ensure that the welding area is effectively ventilated.

3.04 Mains Supply Voltage Requirements

The Mains supply voltage should be within $\pm 15\%$ of the rated mains supply voltage. Too low a voltage may cause poor welding performance. Too high a supply voltage will cause components to overheat and possibly fail.

The Welding Power Source must be:

- Correctly installed, if necessary, by a qualified electrician.
- Correctly earthed (electrically) in accordance with local regulations.
- Connected to the correct size power point and fuse as per the Specifications on page 2-5.



WARNING

Any electrical work must be carried out by a qualified Electrical Tradesperson.

3.05 Electromagnetic Compatibility



WARNING

Extra precautions for Electromagnetic Compatibility may be required when this Welding Power Source is used in a domestic situation.

A. Installation and Use - Users Responsibility

The user is responsible for installing and using the welding equipment according to the manufacturer's instructions. If electromagnetic disturbances are detected then it shall be the responsibility of the user of the welding equipment to resolve the situation with the technical assistance of the

manufacturer. In some cases this remedial action may be as simple as earthing the welding circuit, see NOTE below. In other cases it could involve constructing an electromagnetic screen enclosing the Welding Power Source and the work, complete with associated input filters. In all cases, electromagnetic disturbances shall be reduced to the point where they are no longer troublesome.

NOTE

The welding circuit may or may not be earthed for safety reasons. Changing the earthing arrangements should only be authorised by a person who is competent to assess whether the changes will increase the risk of injury, e.g. by allowing parallel welding current return paths which may damage the earth circuits of other equipment. Further guidance is given in IEC 60974-13 Arc Welding Equipment - Installation and use (under preparation).

B. Assessment of Area

Before installing welding equipment, the user shall make an assessment of potential electromagnetic problems in the surrounding area. The following shall be taken into account

1. Other supply cables, control cables, signalling and telephone cables; above, below and adjacent to the welding equipment.
2. Radio and television transmitters and receivers.
3. Computer and other control equipment.
4. Safety critical equipment, e.g. guarding of industrial equipment.
5. The health of people around, e.g. the use of pacemakers and hearing aids.
6. Equipment used for calibration and measurement.
7. The time of day that welding or other activities are to be carried out.
8. The immunity of other equipment in the environment: the user shall ensure that other equipment being used in the environment is compatible: this may require additional protection measures.

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

C. Methods of Reducing Electromagnetic Emissions**1. Mains Supply**

Welding equipment should be connected to the mains supply according to the manufacturer's recommendations. If interference occurs, it may be necessary to take additional precautions such as filtering of the mains supply. Consideration should be given to shielding the supply cable of permanently installed welding equipment in metallic conduit or equivalent. Shielding should be electrically continuous throughout its length. The shielding should be connected to the Welding Power Source so that good electrical contact is maintained between the conduit and the Welding Power Source enclosure.

2. Maintenance of Welding Equipment

The welding equipment should be routinely maintained according to the manufacturer's recommendations. All access and service doors and covers should be closed and properly fastened when the welding equipment is in operation. The welding equipment should not be modified in any way except for those changes and adjustments covered in the manufacturer's instructions. In particular, the spark gaps of arc striking and stabilising devices should be adjusted and maintained according to the manufacturer's recommendations.

3. Welding Cables

The welding cables should be kept as short as possible and should be positioned close together, running at or close to the floor level.

4. Equipotential Bonding

Bonding of all metallic components in the welding installation and adjacent to it should be considered. However, metallic components bonded to the work piece will increase the risk that the operator could receive a shock by touching the metallic components and the electrode at the same time. The operator should be insulated from all such bonded metallic components.

5. Earthing of the Workpiece


Where the workpiece is not bonded to earth for electrical safety, nor connected to earth because of its size and position, e.g. ship's hull or building steelwork, a connection bonding the workpiece to earth may reduce emissions in some, but not all instances. Care should be

taken to prevent the earthing of the workpiece increasing the risk of injury to users, or damage to other electrical equipment. Where necessary, the connection of the workpiece to earth should be made by direct connection to the workpiece, but in some countries where direct connection is not permitted, the bonding should be achieved by suitable capacitance, selected according to national regulations.

6. Screening and Shielding

Selective screening and shielding of other cables and equipment in the surrounding area may alleviate problems of interference. Screening the entire welding installation may be considered for special applications.

3.06 Transmig 350i, 450i, 550i Power Source Controls, Indicators and Features






Figure 3-1: Front Panel and Controls

1. Amperage Control (Wirespeed)

The amperage control knob adjusts the amount of welding current delivered by the power source.

In MMAW (stick) and GTAW (Lift TIG) modes, the amperage control knob directly adjusts the power inverter to deliver the desired level of output current.

In 10 PIN GMAW/FCAW modes (MIG), the amperage knob adjusts the speed of the 10 pin remote traveller wire feed motor (which in turn adjusts the output current by varying the amount of MIG wire delivered to the welding arc). The optimum wire speed required will be dependent on the welding application.

In 19PIN GMAW/FCAW modes (MIG), the amperage knob is inactive as the wirefeeder speed is adjusted using the control located on the wirefeeder only.

NOTE

The preview functionality provided on this power source is intended to act as a guide only. Some difference may be observed between preview values and actual welding values due to factors including the mode of welding, differences in consumables/gas mixtures, individual welding techniques and the transfer mode of the welding arc (ie dip versus spray transfer). Where exact settings are required (in the case of procedural work), it is recommended that alternate measurement methods be utilized to ensure output values are accurate.

2. Voltage Control

The voltage control knob adjusts the amount of welding voltage delivered by the power source.

In MMAW (stick) and GTAW (Lift TIG) modes, the voltage control knob is inactive.

In 10 PIN and 19 PIN GMAW/FCAW modes (MIG), the voltage knob directly adjusts the power inverter to deliver the desired level of output voltage.

NOTE

The preview functionality provided on this power source is intended to act as a guide only. Some difference may be observed between preview values and actual welding values due to factors including the mode of welding, differences in consumables/gas mixtures, individual welding techniques and the transfer mode of the welding arc (ie dip versus spray transfer). Where exact settings are required (in the case of procedural work), it is recommended that alternate measurement methods be utilized to ensure output values are accurate.

3. Multifunction Control

The multifunction control knob is used to adjust three main parameters depending on the welding mode selected.

When GMAW/FCAW (MIG) Mode is Selected

In this mode the control knob is used to adjust the intensity of the welding arc.

Lower arc control settings make the arc softer with less weld spatter. Higher arc control settings give a stronger driving arc which can increase weld penetration.

When MMAW (Stick) Mode is Selected

In this mode the multifunction control knob is used to adjust arc force. Arc force control provides an adjustable amount of welding force (or “dig”) control. This feature can be particularly beneficial in providing the operator the ability to compensate for variability in joint fit-up in certain situations with particular electrodes. In general increasing the arc force control toward ‘10’ (maximum arc force) allows greater penetration control to be achieved. Arc force is increased by turning the control knob clockwise or decreased by turning the knob anti-clockwise.

When GTAW (Lift Tig) Mode is Selected

In this mode the multifunction control knob is used to adjust down slope. Down slope allows the user to select the ramp down time at the completion of the weld. The main function of down slope is to allow the welding current to be gradually reduced over a pre-set time frame such that the welding pool is given time to cool sufficiently.

Note that when in 2T normal mode (refer item 14), the unit will enter down slope mode as soon as the trigger switch is released (ie if the multifunction control knob is set to 5, the unit will ramp down from the present welding current to zero over 5 seconds). If no down slope time is selected then the welding output will cease immediately. If the unit is set to 4T latch mode, to enter down slope mode the trigger must be held in for the selected time period (ie press and release trigger to commence welding, then press and hold trigger again to enter down slope mode). Should the trigger be released during the down slope phase (4T only), the output will cease immediately.

4. Purge Button

This button will purge the shielding gas when pressed.

The PURGE button is active in 10 PIN GMAW/FCAW (Mig) mode only.

Press and hold the PURGE button to purge the gas line in the Wirefeeder (Active in 10 Pin mode only).

5. Inch Button

The INCH button is active in 10 PIN GMAW/FCAW mode (MIG) only.

Press and hold the INCH button to inch the wire in the Wirefeeder (Active in 10 Pin mode only).

6. Local / Remote Button

The REMOTE button is used to select REMOTE or LOCAL mode of operation.

The REMOTE button is used only when a remote control device (such as a TIG torch with remote current control, or a Wirefeeder) is fitted to the unit via the remote control socket (items 5 & 6). When the REMOTE button is in the remote position, the unit will detect a remote device and work accordingly

When in the local mode, the unit will not detect the remote device and will operate from the power source controls only. Note that the trigger will operate at all times on the remote control socket irrespective of the position of the local remote switch (ie in both local and remote modes).

Should a remote device be connected and the remote/local switch set to remote, the maximum setting of the power source will be determined by the respective front panel control, irrespective of the remote control device setting. As an example, if the output current on the power source front panel is set to 50% and the remote control device is set to 100%, the maximum achievable output from the unit will be 50%.

Should 100% output be required, the respective front panel control must be set to 100%, in which case the remote device will then be able to control between 0-100% output.

7. 10 PIN / 19 PIN Remote Button

The REMOTE button is used to select 10 PIN, 19 PIN, mode of operation when the REMOTE button (item 13) is in REMOTE mode.

When in 10 PIN Remote mode, the 10 PIN control socket is active and remote voltage or current / wire-speed controls will be active.

The 10 PIN Remote mode is only available in GMAW/FCAW (Mig) and GTAW (Lift Tig) modes only.

When in 19 PIN Remote mode, the 19 PIN control socket is active and remote voltage controls will be active.

The 19 PIN Remote mode is only available in GMAW/FCAW (Mig) mode only.

NOTE

When operating a 10 pin Wirefeeder in remote mode, the maximum output is determined by the settings of the power source (in local mode). This is done such that the maximum output available at the wirefeeder can be restricted to a preset level. This preset level must be selected whilst the machine is in local mode.

As an example, should 0-100% output control be required at the wirefeeder, the power source should be set to local mode, and both the amps (wirespeed) and volts controls set to 100% (maximum). the wirefeeder will then be able to control between 0-100% of output [both amps(wire speed) and volts].

Should 50% output be required at the wirefeeder controls, the power source should be set to local mode, and both the amps (wirespeed) and volts set to 50% (mid point). The wirefeeder will then be able to control between 0-50% of output [both amps(wirespeed and volts)]

NOTE

When a 19 pin wirefeeder is used, 100% output for both amps (wirespeed) and volts is available at the wirefeeder at all times regardless of the amps (wirespeed) and volts control settings at the power source (The power source display will show a series of dashes when in 19 pin remote mode). The wirefeeder can adjust both amps (wirespeed) and volts between 0-100%.

NOTE

Welding Setup Program Storage (10 programs) applies to Mig 10 pin only, Stick and Lift Tig modes.

8. Process Selection Button

The process selection control is used to select the desired welding mode. Three modes are available, GMAW/FCAW (MIG), GTAW (Lift TIG) and MMAW (Stick) and Gouging (Transmig 550i only) modes. Refer to section 3.15 or 3.16 for FCAW/GMAW (MIG) set up details, section 3.17 for GTAW (Lift TIG) set-up details or section 3.18 for MMAW (stick) set-up details.

Note that when the unit is powered off the mode selection control will automatically default to MIG mode.

This is necessary so as to prevent inadvertent arcing should an electrode holder be connected to the unit and mistakenly be in contact with the work piece during power up.

9. Trigger Mode Control Button (MIG and LIFT TIG Mode only) (Only applicable to 10 pin mode)

Note that this feature on the power source only applies to devices connected to the 10 pin control socket. In the case of wirefeeders connected to the 19 pin socket the function is controlled from that independent wirefeeder only.

The trigger mode control is used to switch the functionality of the torch trigger between 2T (normal), 4T (latch mode) and SPOT (spot mode)

2T Normal Mode

In this mode, the torch trigger must remain depressed for the welding output to be active. Press and hold the torch trigger to activate the power source (weld). Release the torch trigger switch to cease welding.

4T Latch Mode

This mode of welding is mainly used for long welding runs to reduce operator fatigue. In this mode the operator can press and release the torch trigger and the output will remain active. To deactivate the power source, the trigger switch must again be depressed and realised, thus eliminating the need for the operator to hold the torch trigger.

Note that when operating in GTAW (LIFT TIG mode), the power source will remain activated until the selected down slope time has elapsed (refer Item 10).

SPOT Mode

This mode of welding is similar to 2T mode, except the welding output will be active only for a preset amount of time. This mainly used for tacking at the start of a job setup. Press and hold the torch trigger to activate the power source (weld). After the SPOT time has elapsed and welding output has ceased, release the torch trigger switch.

10. VRD ON/OFF Indicator Lights

A VRD (voltage reduction device) is a hazard reducing device designed to reduce electric shock hazards present on the output of welding power source when operating in MMAW (stick) mode. Note that the presence of VRD should not be used as a substitute for the use of appropriate safety practices as indicated in section one of this manual.

Both the green and red indicator lights only operate in MMAW (stick) mode.

The green VRD ON light illuminates (red light is off) when the VRD is active. Under this condition the open circuit voltage of the unit is limited to below 35V DC, thus reducing the potential of serious electric shock (such as when changing electrodes).

The red VRD OFF light illuminates (green light is off) when the VRD is inactive. Under this condition the output voltage of the unit will be at welding potential which in some cases may exceed 35V DC.

The VRD incorporated within the TRANSMIG 350i, 450i and 550i is fully standards compliant to AS 60974.1 / IEC 60974-1.

11. Thermal Overload Indicator Light (Fault)

This welding power source is protected by a self resetting thermostat. The indicator will illuminate if the duty cycle of the power source has been exceeded. Should the thermal overload indicator illuminate the output of the power source will be disabled. Once the power source cools down this light will go OFF and the over temperature condition will automatically reset. Note that the mains power switch should remain in the on position such that the fan continues to operate thus allowing the unit to cool sufficiently. Do not switch the unit off should a thermal overload condition be present.

12. Program Storage Buttons and Display

This welding power source is able to store 10 machine setups in memory for MIG (10 pin only), Stick and Lift Tig modes. This memory is retained even if mains supply power is turned off. Button status, Amps, Volts, and Wirespeed are stored in memory for quick change between commonly used welding setups.

The memory will store machine setups in all three operating modes, GMAW/FCAW (MIG) (10 Pin only), GTAW (Lift TIG) and MMAW (Stick).

To STORE a program.

Press the number button. The display will change to indicate which program number location is being used.

Press and Hold the SAVE button. The number on the display will flash for 3 seconds.

During this time the current machine setup will be saved in the numbered program location as selected.


To LOAD a program.

Press the NUMBER button. The display will change to indicate which program is being used.

Press the LOAD button. The PROGRAM light will illuminate.

During this time the machine setup will be loaded into the numbered program location and locked in. To unlock this press the load button again and the program light will go off.

At any time after a SAVE or LOAD has been performed, manual adjustment of Volts, Amps, Wirespeed or any button press will return the unit to manual operating mode.



13. Digital Ammeter / Wirefeed Speed / Spot time meter

The digital amperage meter is used to display both the pre-set current (Stick and TIG modes only) and actual output current (all modes) of the power source. It is also used to display Wirefeed speed and SPOT time.


At times of non-welding, the amperage meter will display a pre-set (preview) value in both MMAW (Stick) and GTAW (LIFT TIG) modes. This value can be adjusted by varying the amperage control (item 8) and the AMPS light will illuminate to indicate AMPS are being displayed.

In 10 PIN GMAW/FCAW (MIG) mode, the amperage meter will preview wirefeed speed. The IPM (inches per minute) or MPM (metres per minute) light will illuminate to indicate which wirespeed scale is being used.

In 19 PIN GMAW/FCAW (MIG) mode, the amperage meter will read zero.

When welding, the amperage meter will display actual welding current in all modes.

At the completion of welding, the amperage meter will hold the last recorded amperage value for a period of approximately 10 seconds in all modes. The amperage meter will hold the value until; (1) any of the front panel controls are adjusted in which case the unit will revert to preview mode, (2) welding is recommenced, in which case actual welding amperage will be displayed, or (3) a period of 10 seconds elapses following the completion of welding in which case the unit will return to preview mode.



NOTE


The preview functionality provided on this power source is intended to act as a guide only. Some difference may be observed between preview values and actual welding values due to factors including the mode of welding, differences in consumables/gas mixtures, individual welding techniques and the transfer mode of the welding arc (ie dip versus spray transfer). Where exact settings are required (in the case of procedural work), it is recommended that alternate measurement methods be utilized to ensure output values are accurate.

14. Digital Voltmeter / Inductance meter (MIG) / Downslope (TIG) / Arc Force (Stick)

The digital volt meter is used to display both the pre-set voltage (MIG mode only) and actual output voltage (all modes) of the power source. It is also used to display inductance and down slope time.

At times of non-welding, the VOLT meter will display a pre-set (preview) value in GMAW (MIG) mode.


This value can be adjusted by varying the volts control (item 9) and the VOLTS light will illuminate to indicate VOLTS are being displayed.



A-10632_AB

When welding, the volt meter will display actual welding voltage in all modes.

At the completion of welding, the volt meter will hold the last recorded voltage value for a period of approximately 10 seconds in all modes. The volt meter will hold the value until; (1) any of the front panel controls are adjusted in which case the unit will revert to preview mode, (2) welding is recommenced, in which case actual welding voltage will be displayed, or (3) a period of 10 seconds elapses following the completion of welding in which case the unit will return to preview mode.

In MIG mode when setting the INDUCTANCE value, the  light will illuminate, and the display will read INDUCTANCE. The range of adjustment is from 0 to 100.

In TIG mode when setting DOWNSLOPE the SEC light will illuminate, and the display will read DOWNSLOPE. The range of adjustment is from 0 to 10 seconds.

In Stick mode when setting the ARCFORCE the display will read ARCFORCE. The range of adjustment is from 0 to 100.

Arc force control provides an adjustable amount of welding force (or "dig") control. This feature can be particularly beneficial in providing the operator the ability to compensate for variability in joint fit-up in certain situations with particular electrodes. In general increasing the arc force control toward "100" (maximum arc force) allows greater penetration control to be achieved. Arc force is increased by turning the control knob clockwise or decreased by turning the knob anti-clockwise.

NOTE

The preview functionality provided on this power source is intended to act as a guide only. Some difference may be observed between preview values and actual welding values due to factors including the mode of welding, differences in consumables/gas mixtures, individual welding techniques and the transfer mode of the welding arc (ie dip versus spray transfer). Where exact settings are required (in the case of procedural work), it is recommended that alternate measurement methods be utilized to ensure output values are accurate.

TRANSMIG 350i, 450i, 550i

15. Advanced Features

The TRANSMIG 350i, 450i and 550i have a series of Advanced features that allow the control of multiple parameters.

These are accessed by pressing the AMPS and VOLTS knobs at the same time.

Once in the Advanced Features mode, turn the AMP control to select the Parameter, and turn the VOLTS control to adjust the value.




Figure 3-2: Advanced Features



| Program Number | Description |
|--|--|
|  <p>A-10634</p> |  <p>A-10635</p> |
| P01 | SPOT TIME, adjustable from 0.5 to 5.0 seconds |
| P02 | BURN BACK TIME, adjustable from 0.01 to 2.00 seconds |
| P03 | PRE FLOW TIME, adjustable from 0.01 to 9.99 seconds |
| P04 | POST FLOW TIME, adjustable from 0.01 to 9.99 seconds |
| P05 | MMAW (Stick) HOT START CURRENT, adjustable from 10 to 100A |
| P06 | CREEP FEED SPEED, adjustable from 0.05 to 20 MPM |
| P07 | Wirefeed speed units, change between IPM and MPM |
| P08 | Displays Software revision |

Table 3-1: Advanced Features

16. Fan as Needed

The TRANSMIG 350i, 450i and 550i are fitted with a fan as needed feature. Fan as needed automatically switches the cooling fan off when it is not required. This has two main advantages; (1) to minimize power consumption, and (2) to minimise the amount of contaminants such as dust that are drawn into the power source.

Note that the fan will only operate when required for cooling purposes and will automatically switch off when not required.

17. Main Three Phase Power On / Off Switch

This Three Phase circuit breaker performs a dual function.

It is used to turn the unit on/off and it will also trip in the event of a major fault condition.

Lift the cover for access to the circuit breaker.

**WARNING**

When the front digital displays are lit, the machine is connected to the Mains supply voltage and the internal electrical components are at Mains voltage potential

18. Positive Welding Terminal

Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.

19. Negative Welding Terminal

Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.


**CAUTION**

Loose welding terminal connections can cause overheating and result in the male plug being fused in the terminal.

20.10 Pin Control Socket

The 10 pin receptacle is used to connect a Wirefeeder or other suitable remote control device to the welding Power Source circuitry:

To make connections, align keyway, insert plug, and rotate threaded collar fully clockwise. The socket information is included in the event the supplied cable is not suitable and it is necessary to wire a plug or cable to interface with the 10 pin receptacle




A-10636

| Socket Pin | Part Number / Description |
|------------|---|
| A | Remote Voltage Control Potentiometer Wiper |
| B | Motor Negative |
| C | Motor Positive |
| D | Contactor + (Contact closure is provided between socket pins D and G to energise the contactor) |
| E | Remote Voltage & Wirespeed Control Potentiometers Maximum |
| F | Remote Wirespeed Control Potentiometer Wiper |
| G | Contactor Negative, Solenoid Negative |
| H | Remote Voltage & Wirespeed Control Potentiometers Minimum |
| I | Solenoid Positive |
| J | Not used |

Table 3-2: 10 Pin Interconnection Control Plug configuration

21.19 Pin Wirefeeder Control Socket

The WIREFEEDER 19 pin receptacle is used to connect a Wirefeeder to the welding Power Source circuitry. To make connections, align keyway, insert plug, and rotate threaded collar fully clockwise. The socket information is included in the event the supplied cable is not suitable and it is necessary to wire a plug or cable to interface with the WIREFEEDER 19 pin receptacle.



A-10637

| Socket Pin | Part Number / Description |
|------------|---|
| A | Contactor + (Contact closure is provided between socket pins A and B to energise the contactor) |
| B | Contactor - (Contact closure is provided between socket pins A and B to energise the contactor) |
| C | Voltage feedback (1V=10V output voltage) |
| D | Not used |
| E | Input Supply 110VAC 4A with respect to Socket F (circuit common) |
| F | 42VAC and 110VAC common |
| G | Chassis Ground (Mains Earth) |
| H | Remote Voltage Control Potentiometers Maximum |
| J | Remote Voltage Control Potentiometer Wiper |
| K | Remote Voltage Control Potentiometers Minimum |
| L | Control circuit common |
| M | Arc Established = +15V DC |
| N | Power Source Select Line (0V = wirefeeder enabled) |
| P | Not used |
| R | Not used |
| S | Input Supply 42VAC 8A with respect to Socket F (circuit common) |
| T | Not used |
| U | Current feedback (1V=100A output current) |
| V | Not used |

Table 3-3: 19 Pin Interconnection Control Plug configuration



WARNING

The Protective Earth Ground pin G of the control cable is established only when the power source is properly grounded

22. Control Circuit Breakers




Figure 3-3: Circuit Breakers

These Circuit Breakers protect the unit from electrical faults.

The SOLENOID 4A and MOTOR 5A circuit breakers are for Wirefeeders connected to the 10 pin control socket. The 42VAC 8A and 110VAC 4A circuit breakers are for Wirefeeders connected to the 19 pin control socket. The Fan 3A circuit breaker protects the fan circuit in the event of a fault.

NOTE

If a circuit breaker trips, a short cooling period must be allowed before an attempt is made to reset the unit by pressing the circuit breaker reset button. In the event that the circuit breaker will not reset have an Accredited Cigweld Service provider investigate the fault.

23. Restore Factory Default Settings

The Transmig 350i, 450i and 550i can have Factory Default Settings Restored. This function is accessed by pressing the AMPS and INDUCTANCE knobs at the same time for two seconds (2s). The VOLTS and AMPS led's will flash 3 times to indicate a Factory Reset has been completed.




Figure 3-4: Restore Factory Default Settings

3.07 Shielding Gas Regulator Operating Instructions



WARNING

This equipment is designed for use with welding grade (Inert) shielding gases only.

Shielding Gas Regulator Safety

This regulator is designed to reduce and control high pressure gas from a cylinder or pipeline to the working pressure required for the equipment using it.

If the equipment is improperly used, hazardous conditions are created that may cause accidents. It is the users responsibility to prevent such conditions. Before handling or using the equipment, understand and comply at all times with the safe practices prescribed in this instruction.

SPECIFIC PROCEDURES for the use of regulators are listed below.

1. NEVER subject the regulator to inlet pressure greater than its rated inlet pressure.
2. NEVER pressurize a regulator that has loose or damaged parts or is in a questionable condition. NEVER loosen a connection or attempt to remove any part of a regulator until the gas pressure has been relieved. Under pressure, gas can dangerously propel a loose part.
3. DO NOT remove the regulator from a cylinder without first closing the cylinder valve and releasing gas in the regulator high and low pressure chambers.
4. DO NOT use the regulator as a control valve. When downstream equipment is not in use for extended periods of time, shut off the gas at the cylinder valve and release the gas from the equipment.
5. OPEN the cylinder valve SLOWLY. Close after use.

User Responsibilities

This equipment will perform safely and reliable only when installed, operated and maintained, and repaired in accordance with the instructions provided. Equipment must be checked periodically and repaired, replaced, or reset as necessary for continued safe and reliable performance. Defective equipment should not be used. Parts that are broken, missing, obviously worn, distorted, or contaminated should be replaced immediately.

The user of this equipment will generally have the sole responsibility for any malfunction, which results from improper use, faulty maintenance, or by repair by anyone other than an accredited repairer.



CAUTION

Match regulator to cylinder. NEVER CONNECT a regulator designed for a particular gas or gases to a cylinder containing any other gas.




Figure 3-5: Fit Regulator to Cylinder

Installation

1. Remove cylinder valve plastic dust seal. Clean the cylinder valve outlet of impurities that may clog orifices and damage seats before connecting the regulator.

Crack the valve (open then close) momentarily, pointing the outlet away from people and sources of ignition. Wipe with a clean lint free cloth.
2. Match regulator to cylinder. Before connecting, check that the regulator label and cylinder marking agree and that the regulator inlet and cylinder outlet match. NEVER CONNECT a regulator designed for a particular gas or gases to a cylinder containing any other gas.
3. Connect the regulator inlet connection to cylinder or pipeline and tighten it firmly but not excessively, with a suitable spanner.
4. Connect and tighten the outlet hose firmly and attach down-stream equipment.
5. To protect sensitive down-stream equipment a separate safety device may be necessary if the regulator is not fitted with a pressure relief device.

Operation

With the regulator connected to cylinder or pipeline, and the adjustment screw/knob fully disengaged, pressurize as follows:

1. Stand to one side of regulator and slowly open the cylinder valve. If opened quickly, a sudden pressure surge may damage internal regulator parts.
2. With valves on downstream equipment closed, adjust regulator to approximate working pressure. It is recommended that testing for leaks at the regulator connection points be carried out using a suitable leak detection solution or soapy water.
3. Purge air or other unwanted welding grade shielding gas from equipment connected to the regulator by individually opening then closing the equipment control valves. Complete purging may take up to ten seconds or more, depending upon the length and size of the hose being purged.

Adjusting Flow Rate




Figure 3-6: Adjust Flow Rate

With the regulator ready for operation, adjust working flow rate as follows:

1. Slowly turn adjusting screw/knob in (clockwise) direction until the outlet gauge indicates the required flow rate.

NOTE

It may be necessary to re-check the shielding gas regulator flow rate following the first weld sequence due to back pressure present within shielding gas hose assembly.

2. To reduce flow rate, allow the welding grade shielding gas to discharge from regulator by opening the downstream valve. Bleed welding grade shielding gas into a well ventilated area and away from any ignition source. Turn adjusting screw counterclockwise, until the required flow rate is indicated on the gauge. Close downstream valve.

Shutdown

Close cylinder valve whenever the regulator is not in use. To shut down for extended periods (more than 30 minutes).

1. Close cylinder or upstream valve tightly.
2. Open downstream equipment valves to drain the lines. Bleed gas into a well ventilated area and away from any ignition source.
3. After gas is drained completely, disengage adjusting screw and close downstream equipment valves.
4. Before transporting cylinders that are not secured on a cart designed for such purposes, remove regulators.

3.08 Setup for MIG (GMAW) Welding with Gas Shielded Mig Wire

POWER SOURCE CONNECTIONS

- A. Remove all packaging materials. Do not block the air vents at the front or rear of the Power Source.
- B. Connect the work lead to the negative welding terminal (-) [positive welding terminal(+) for flux cored electrode wire]. If in doubt, consult the electrode wire manufacturer. Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.

**CAUTION**

Loose welding terminal connections can cause overheating and result in the male plug being fused in the terminal.

**WARNING**

Before connecting the work clamp to the work piece make sure the mains power supply is switched off.

Secure the welding grade shielding gas cylinder in an upright position by chaining it to a suitable stationary support to prevent falling or tipping.


- C. Position a gas cylinder on the rear tray of the Power Source and lock securely to the Power Source cylinder bracket with the chain provided. If this arrangement is not used or the Power Source is not fitted with a gas cylinder tray then ensure that the gas cylinder is secured to a building pillar, wall bracket or otherwise securely fixed in an upright position.
- D. Select MIG mode with the process selection control button.

WIREFEEDER CONNECTIONS

- A. Connect the welding power cable from the Wirefeeder's interconnection cables to the positive welding terminal (+) [negative welding terminal (-) for flux cored electrode wire]. If in doubt, consult the electrode wire manufacturer. Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.
- B. Connect the control cable from the Wirefeeder to the 10 PIN or 19 PIN socket on the Power Source as applicable.

TRANSMIG 350i, 450i, 550i

- C. Fit the gas regulator and flowmeter to the gas cylinder then connect the gas hose from the rear of the Wirefeeder to the flowmeter outlet.
- D. Dual groove feed rollers are supplied as standard. Select the roller required with the chosen wire size marking facing outwards.



- E. Fit the electrode wire spool to the wire reel hub. Ensure that the drive dog-pin engages the mating hole in the wire spool. Push the 'R' clip into place to retain the wire spool securely. The electrode wire should feed from the bottom of the spool.

F MIG Torch, EURO MIG Torch Connection

Fit the MIG Torch to the Wirefeeder by pushing the torch connector into the brass torch adaptor and screwing the plastic torch nut clockwise to secure the torch to the torch adaptor. Remove the contact tip from the torch handset.

TWECO style Torch Connection

Fit the MIG Torch to the Wirefeeder by pushing the torch connector into the brass torch adaptor and screwing the hand nut clockwise to secure the torch to the torch adaptor. Remove the contact tip from the torch handset. Attach the wirefeeder trigger wires to the MIG Torch.

- G Lift up the wire feeder pressure levers and pass the electrode wire through the inlet guide, between the rollers, through the centre guide, between the rollers, through the outlet guide and into the MIG torch.



WARNING

DO NOT WEAR GLOVES WHILE THREADING THE WIRE OR CHANGING THE WIRE SPOOL.

- H. Lower the pressure levers and with the torch lead reasonably straight, feed the electrode wire through the torch. Fit the appropriate contact tip, eg a 0.9mm tip for 0.9mm wire.
- I Press the INCH button to feed the wire through the torch. (Only applicable to wirefeeders connected to the 10 pin socket. Wirefeeders connected to the 19 pin socket can only be inched from the wirefeeder itself if that function is available.)



WARNING

If the Torch Trigger is used to feed wire through the torch, the electrode wire will be at welding voltage potential whilst it is being fed through the wirefeeder system.



WARNING

Before connecting the work clamp to the work piece make sure the mains power supply is switched off.

NOTE

Welding Setup Program Storage (10 programs) applies to MIG (10 pin only), Stick and Lift Tig modes.




Figure 3-7: Setup for Mig Welding with Gas Shielded Mig Wire

3.09 Setup for MIG (GMAW) Welding with Gasless Mig Wire

POWER SOURCE CONNECTIONS

- A. Remove all packaging materials. Do not block the air vents at the front or rear of the Power Source.
- B. Connect the work lead to the positive welding terminal (+). If in doubt, consult the electrode wire manufacturer. Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.



CAUTION

Loose welding terminal connections can cause overheating and result in the male plug being fused in the terminal.




WARNING

Before connecting the work clamp to the work piece make sure the mains power supply is switched off.

- C. Select MIG mode with the process selection control button.

WIREFEEDER CONNECTIONS

- A. Connect the welding power cable from the Wirefeeder's interconnection cables to the negative welding terminal (-). If in doubt, consult the electrode wire manufacturer. Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.
- B. Connect the control cable from the Wirefeeder to the 10 PIN or 19 PIN socket on the Power Source as applicable.
- C. Dual groove feed rollers are supplied as standard. Select the roller required with the chosen wire size marking facing outwards.



- D. Fit the electrode wire spool to the wire reel hub. Ensure that the drive dog-pin engages the mating hole in the wire spool. Push the 'R' clip into place to retain the wire spool securely. The electrode wire should feed from the bottom of the spool.
- E. MIG Torch, EURO MIG Torch Connection

Fit the MIG Torch to the Wirefeeder by pushing the torch connector into the brass torch adaptor and screwing the plastic torch nut clockwise to secure the torch to the torch adaptor. Remove the contact tip from the torch handset.

TWECO style Torch Connection

Fit the MIG Torch to the Wirefeeder by pushing the torch connector into the brass torch adaptor and screwing the hand nut clockwise to secure the torch to the torch adaptor. Remove the contact tip from the torch handset. Attach the wirefeeder trigger wires to the MIG Torch.

- F. Lift up the wire feeder pressure levers and pass the electrode wire through the inlet guide, between the rollers, through the centre guide, between the rollers, through the outlet guide and into the MIG torch.

**WARNING**

DO NOT WEAR GLOVES WHILE THREADING THE WIRE OR CHANGING THE WIRE SPOOL.

- G. Lower the pressure levers and with the torch lead reasonably straight, feed the electrode wire through the torch. Fit the appropriate contact tip, eg a 0.9mm tip for 0.9mm wire.
- H. Press the INCH button to feed the wire through the torch. (Only applicable to wirefeeders connected to the 10 pin socket. Wirefeeders connected to the 19 pin socket can only be inched from the wirefeeder itself if that function is available.)

**WARNING**

If the Torch Trigger is used to feed wire through the torch, the electrode wire will be at welding voltage potential whilst it is being fed through the wirefeeder system.

**WARNING**

Before connecting the work clamp to the work piece make sure the mains power supply is switched off.

NOTE

Welding Setup Program Storage (10 programs) applies to MIG (10 pin only), Stick and Lift Tig modes.




Figure 3-8: Setup for Mig Welding with Gasless Mig Wire

3.10 Setup for TIG (GTAW) Welding With Gas Shielding

- A. Remove all packaging materials. Do not block the air vents at the front or rear of the Power Source.
- B. Connect the work lead to the positive welding terminal (+). Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.
- C. Connect the optional TIG Torch (refer to table 2-2 optional accessories) to the negative welding terminal (-). Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.



CAUTION

Loose welding terminal connections can cause overheating and result in the male plug being fused in the terminal.



WARNING

Before connecting the work clamp to the work piece make sure the mains power supply is switched off.

Secure the welding grade shielding gas cylinder in an upright position by chaining it to a suitable stationary support to prevent falling or tipping.

- D. Position a gas cylinder on the rear tray of the Power Source and lock securely to the Power Source cylinder bracket with the chain provided. If this arrangement is not used or the Power Source is not fitted with a gas cylinder tray then ensure that the gas cylinder is secured to a building pillar, wall bracket or otherwise securely fixed in an upright position.
- E. Select LIFT TIG mode with the process selection control button.
- F. Connect the TIG Torch trigger switch / remote control to the 10 PIN socket on the Power Source as applicable. The TIG Torch will require a trigger switch to operate in LIFT TIG mode.
- G. Fit the gas regulator and flowmeter to the gas cylinder then connect the gas hose from the TIG Torch to the Flowmeter outlet. The Power Source is not fitted with a shielding gas solenoid to control the gas flow in LIFT TIG mode, therefore the TIG Torch will require a gas valve.




Figure 3-9: Setup for TIG (GTAW) Welding with Gas Shielding

3.11 Setup for STICK (MMAW) Welding

- A. Remove all packaging materials. Do not block the air vents at the front or rear of the Power Source.
- B. Connect the Electrode Holder to the positive welding terminal (+). If in doubt, consult the electrode manufacturer. Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.
- C. Connect the work lead to the negative welding terminal (-). If in doubt, consult the electrode manufacturer. Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.



CAUTION

Loose welding terminal connections can cause overheating and result in the male plug being fused in the terminal.



WARNING

Before connecting the work clamp to the workpiece make sure the mains power supply is switched off.

- D. Select STICK mode with the process selection control button




Figure 3-10: Setup for Manual Arc Welding.

3.12 Setup for GOUGING (Transmig 550i only)

- A. Remove all packaging materials. Do not block the air vents at the front or rear of the Power Source.
- B. Connect the Carbon Arc Gouging Torch to the positive welding terminal (+). If in doubt, consult the carbon electrode manufacturer. Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.
- C. Connect the work lead to the negative welding terminal (-). If in doubt, consult the electrode manufacturer. Welding current flows from the Power Source via heavy duty bayonet type terminals. It is essential, however, that the male plug is inserted and turned securely to achieve a sound electrical connection.
- D. Connect the air hose from the Carbon Arc Gouging Torch to a Filtered, Industrial, Compressed air outlet and set pressure to the Carbon Arc Gouging Torch manufacturers specification.
- E. Select STICK / GOUGING mode with the process selection control button (Transmig 550i only).



CAUTION

Refer to Section 2.10 & 2.11 for Gouging Ratings and Duty Cycle Period.



WARNING

Before connecting the work clamp to the workpiece make sure the mains power supply is switched off.





Figure 3-11: Setup for Gouging

SECTION 4: BASIC WELDING GUIDE

4.01 MIG (GMAW/FCAW) Basic Welding Technique

Two different welding processes are covered in this section (GMAW and FCAW), with the intention of providing the very basic concepts in using the Mig mode of welding, where a welding gun is hand held, and the electrode (welding wire) is fed into a weld puddle, and the arc is shielded by an inert welding grade shielding gas or inert welding grade shielding gas mixture.


GAS METAL ARC WELDING (GMAW): This process, also known as MIG welding, CO₂ welding, Micro Wire Welding, short arc welding, dip transfer welding, wire welding etc., is an electric arc welding process which fuses together the parts to be welded by heating them with an arc between a solid continuous, consumable electrode and the work. Shielding is obtained from an externally supplied welding grade shielding gas or welding grade shielding gas mixture. The process is normally applied semi automatically; however the process may be operated automatically and can be machine operated. The process can be used to weld thin and fairly thick steels, and some non-ferrous metals in all positions.



GMAW Process Art # A-8991_AB

Figure 4-1

FLUX CORED ARC WELDING (FCAW): This is an electric arc welding process which fuses together the parts to be welded by heating them with an arc between a continuous flux filled electrode wire and the work. Shielding is obtained through decomposition of the flux within the tubular wire. Additional shielding may or may not be obtained from an externally supplied gas or gas mixture. The process is normally applied semi automatically; however the process may be applied automatically or by machine. It is commonly used to weld large diameter electrodes in the flat and horizontal position and small electrode diameters in all positions. The process is used to a lesser degree for welding stainless steel and for overlay work.



FCAW Process Art # A-08992_AB

Figure 4-2

Position of MIG Torch

The angle of MIG torch to the weld has an effect on the width of the weld.




Figure 4-3

The welding gun should be held at an angle to the weld joint. (see Secondary Adjustment Variables below)


Hold the gun so that the welding seam is viewed at all times. Always wear the welding helmet with proper filter lenses and use the proper safety equipment.



CAUTION


Do not pull the welding gun back when the arc is established. This will create excessive wire extension (stick-out) and make a very poor weld.

The electrode wire is not energized until the gun trigger switch is depressed. The wire may therefore be placed on the seam or joint prior to lowering the helmet.




Butt & Horizontal Welds

Figure 4-4




Horizontal Fillet Weld

Figure 4-5


Vertical Fillet Welds

Art # A-08995

Figure 4-6


Art # A-08996

Overhead Weld
Figure 4-7

Distance from the MIG Torch Nozzle to the Work Piece

The electrode wire stick out from the MIG Torch nozzle should be between 10mm to 20.0mm. This distance may vary depending on the type of joint that is being welded.

Travel Speed

The speed at which the molten pool travels influences the width of the weld and penetration of the welding run.

MIG Welding (GMAW) Variables

Most of the welding done by all processes is on carbon steel. The items below describe the welding variables in short-arc welding of 24gauge (0.024", 0.6mm) to ¼" (6.4mm) mild sheet or plate. The applied techniques and end results in the GMAW process are controlled by these variables.

Preselected Variables

Preselected variables depend upon the type of material being welded, the thickness of the material, the welding position, the deposition rate and the mechanical properties. These variables are:

- Type of electrode wire
- Size of electrode wire
- Type of gas (not applicable to self shielding wires FCAW)
- Gas flow rate (not applicable to self shielding wires FCAW)

Primary Adjustable Variables

These control the process after preselected variables have been found. They control the penetration, bead width, bead height, arc stability, deposition rate and weld soundness. They are:

- Arc Voltage
- Welding current (wire feed speed)
- Travel speed

Secondary Adjustable Variables

These variables cause changes in primary adjustable variables which in turn cause the desired change in the bead formation. They are:

1. Stick-out (distance between the end of the contact tube (tip) and the end of the electrode wire). Maintain at about 10mm stick-out
2. Wire Feed Speed. Increase in wire feed speed increases weld current, Decrease in wire feed speed decreases weld current.




Figure 4-8

3. Nozzle Angle. This refers to the position of the welding gun in relation to the joint. The transverse angle is usually one half the included angle between plates forming the joint. The longitudinal angle is the angle between the centre line of the welding gun and a line perpendicular to the axis of the weld. The longitudinal angle is generally called the Nozzle Angle and can be either trailing (pulling) or leading (pushing). Whether the operator is left handed or right handed has to be considered to realize the effects of each angle in relation to the direction of travel.




Figure 4-9




Figure 4-10

Establishing the Arc and Making Weld Beads

Before attempting to weld on a finished piece of work, it is recommended that practice welds be made on a sample metal of the same material as that of the finished piece.

The easiest welding procedure for the beginner to experiment with MIG welding is the flat position. The equipment is capable of flat, vertical and overhead positions.

For practicing MIG welding, secure some pieces of 16 or 18 gauge (0.06" 1.5mm or 0.08" 2.0mm) mild steel plate 6" x 6" (150 x 150mm). Use 0.030" (0.8mm) flux cored gasless wire or a solid wire with shielding gas.

Setting of the Power Source

Power source and Wirefeeder setting requires some practice by the operator, as the welding plant has two control settings that have to balance. These are the Wirespeed control (refer to section 3.06.4) and the welding Voltage Control (refer to section 3.06.10). The welding current is determined by the Wirespeed control, the current will increase with increased Wirespeed, resulting in a shorter arc. Less wire speed will reduce the current and lengthen the arc. Increasing the welding voltage hardly alters the current level, but lengthens the arc. By decreasing the voltage, a shorter arc is obtained with a little change in current level.

When changing to a different electrode wire diameter, different control settings are required. A thinner electrode wire needs more Wirespeed to achieve the same current level.

A satisfactory weld cannot be obtained if the Wirespeed and Voltage settings are not adjusted to suit the electrode wire diameter and the dimensions of the work piece.

If the Wirespeed is too high for the welding voltage, "stubbing" will occur as the wire dips into the molten pool and does not melt. Welding in these conditions normally produces a poor weld due to lack of fusion. If, however, the welding voltage is too high, large drops will form on the end of the wire, causing spatter. The correct setting of voltage and Wirespeed can be seen in the shape of the weld deposit and heard by a smooth regular arc sound. Refer to the Weld Guide located on the inside of the wirefeed compartment door for setup information.

Electrode Wire Size Selection

The choice of Electrode wire size and shielding gas used depends on the following

- Thickness of the metal to be welded
- Type of joint
- Capacity of the wire feed unit and Power Source
- The amount of penetration required
- The deposition rate required
- The bead profile desired
- The position of welding
- Cost of the wire


350i, 450i, 550i

Cigweld Welding Wire Selection Chart

| Description | Diameter | Pack | Part Number | Application |
|---|----------|----------------|-------------|--|
| Shield-Cor 11 | 1.2mm | Spool 15kg | 720923 | Shield-Cor 11 is an all positional self-shielded flux cored wire recommended for the general purpose single or multi-pass lap, fillet and butt welding of mild and galvanised steels. |
| | 1.6mm | Spool 15kg | 720925 | |
| Verti-Cor 3XP | 1.2mm | Spool 15kg | 720919 | Verti-Cor 3XP is an all positional rutile type flux cored wire for welding a wide range of mild and medium strength steels. Verti-Cor 3XP is for use with Argon+20 to 25% CO ₂ or 100% CO ₂ type shielding gases. |
| | 1.6mm | Spool 15kg | 720921 | |
| Autocraft LW1-6 | 0.8mm | Spool 15kg | 720114 | General purpose solid welding wire suitable for the all positional Gas Metal Arc Welding (GMAW) of mild and low alloy steels, used in general fabrication and for welding of light to medium gauge sheet and tubular steel sections. Note that a suitable shielding gas is required. |
| | 0.9mm | Handispool 5kg | 720161 | |
| | 0.9mm | Spool 15kg | 720090 | |
| | 1.0mm | Spool 15kg | 720094 | |
| | 1.2mm | Spool 15kg | 720096 | |
| | 1.6mm | Spool 15kg | 720095 | |
| Autocraft 316LSi Solid Stainless Steel Mig Wire | 0.8mm | Handispool 5kg | 720288 | General purpose all positional stainless steel wire providing excellent results when used with correct shielding gas. Suitable for the general welding of a wide range of stainless steels (300 & 400 series). Note that a suitable shielding gas is required. |
| | 0.9mm | Handispool 5kg | 720283 | |
| | 0.9mm | Spool 15kg | 721286 | |
| | 1.0mm | Spool 15kg | 722386 | |
| | 1.2mm | Spool 15kg | 721287 | |
| Autocraft AL5356 Solid Aluminium Mig Wire | 0.9mm | Spool 7kg | 722226 | Excellent general purpose Aluminium Mig wire suitable for the welding of a wide range of wrought and cast Aluminium alloys containing Magnesium. Note that a suitable shielding gas is required. |
| | 1.0mm | Handispool 2kg | 723224 | |
| | 1.0mm | Spool 7kg | 722224 | |
| | 1.2mm | Spool 7kg | 722227 | |

Note Handispool = 200mm diameter, Spool = 300mm diameter.

4.02 MIG (GMAW/FCAW) Welding Troubleshooting

Solving Problems Beyond the Welding Terminals

The general approach to fix Gas Metal Arc Welding (GMAW) problems is to start at the wire spool then work through to the MIG torch. There are two main areas where problems occur with GMAW, Porosity and Inconsistent wire feed

Solving Problems Beyond the Welding Terminals - Porosity

When there is a gas problem the result is usually porosity within the weld metal. Porosity always stems from some contaminant within the molten weld pool which is in the process of escaping during solidification of the molten metal. Contaminants range from no gas around the welding arc to dirt on the work piece surface. Porosity can be reduced by checking the following points.

| FAULT | CAUSE |
|---|--|
| 1 Shielding gas cylinder contents and flow meter. | Ensure that the shielding gas cylinder is not empty and the flow meter is correctly adjusted to 15 litres per minute. |
| 2 Gas leaks. | Check for gas leaks between the regulator/cylinder connection and in the gas hose to the Power Source. |
| 3 Internal gas hose in the Power Source. | Ensure the hose from the solenoid valve to the torch adaptor has not fractured and that it is connected to the torch adaptor. |
| 4 Welding in a windy environment. | Shield the weld area from the wind or increase the gas flow. |
| 5 Welding dirty, oily, painted, oxidised or greasy plate. | Clean contaminates off the work piece. |
| 6 Distance between the MIG torch nozzle and the work piece. | Keep the distance between the MIG torch nozzle and the work piece to a minimum. Refer to section 2.03 |
| 7 Maintain the MIG torch in good working order. | <p>A Ensure that the gas holes are not blocked and gas is exiting out of the torch nozzle.</p> <p>B Do not restrict gas flow by allowing spatter to build up inside the torch nozzle.</p> <p>C Check that the MIG torch O-rings are not damaged.</p> |

Table 4-1: Solving Problems beyond the Welding Terminals-Porosity



WARNING

Disengage the feed roll when testing for gas flow by ear.

Solving Problems Beyond the Welding Terminals - Inconsistent Wire Feed

Wire feeding problems can be reduced by checking the following points.

| FAULT | CAUSE |
|--|---|
| 1 Feed roller driven by motor in the cabinet slipped. | Wire spool brake is too tight. |
| 2 Wire spool unwinded and tangled. | Wire spool brake is too loose. |
| 3 Worn or incorrect feed roller size | A Use a feed roller matched to the size you are welding. B Replace feed roller if worn. |
| 4 Wire rubbed against the mis-aligned guides and reduced wire feedability. | Mis-alignment of inlet/outlet guides |
| 5 Liner blocked with swarf | A Increased amounts of swarf are produced by the wire passing through the feed roller when excessive pressure is applied to the pressure roller adjuster. B Swarf can also be produced by the wire passing through an incorrect feed roller groove shape or size. C Swarf is fed into the conduit liner where it accumulates thus reducing wire feedability. |
| 6 Incorrect or worn contact tip | A The contact tip transfers the weld current to the electrode wire. If the hole in the contact tip is too large then arcing may occur inside the contact tip resulting in the wire jamming in the contact tip B When using soft wire such as aluminium it may become jammed in the contact tip due to expansion of the wire when heated. A contact tip designed for soft wires should be used. |
| 7 Poor work lead contact to work piece | If the work lead has a poor electrical contact to the work piece then the connection point will heat up and result in a reduction of power at the arc. |
| 8 Bent liner | This will cause friction between the wire and the liner thus reducing wire feedability |

Table 4-2: Wire Feeding Problems

Basic GMAW (MIG) Welding Troubleshooting

| FAULT | CAUSE | REMEDY |
|---|--|---|
| 1 Undercut | A Welding arc voltage too high. B Incorrect torch angle C Excessive heat input | A Decrease voltage or increase the wire feed speed. B Adjust angle. C Increase the torch travel speed and/or decrease welding current by decreasing the voltage or decreasing the wire feed speed. |
| 2 Lack of penetration | A Welding current too low B Joint preparation too narrow or gap too tight C Shielding gas incorrect | A Increase welding current by increasing wire feed speed and increasing voltage. B Increase joint angle or gap. C Change to a gas which gives higher penetration. |
| 3 Lack of fusion | Voltage too low | Increase voltage. |
| 4 Excessive spatter | A Voltage too high B Voltage too low | A Decrease voltage or increase the wirespeed control. B Increase the voltage or decrease wirespeed. |
| 5 Irregular weld shape | A Incorrect voltage and current settings. Convex, voltage too low. Concave, voltage too high. B Wire is wandering. C Incorrect shielding gas D Insufficient or excessive heat input | A Adjust voltage and current by adjusting the voltage control and the wirespeed control. B Replace contact tip. C Check shielding gas. D Adjust the wirespeed control or the voltage control. |
| 6 Weld cracking | A Weld beads too small B Weld penetration narrow and deep C Excessive weld stresses D Excessive voltage E Cooling rate too fast | A Decrease travel speed B Reduce current and voltage and increase Mig torch travel speed or select a lower penetration shielding gas. C Increase weld metal strength or revise design D Decrease voltage. E Slow the cooling rate by preheating part to be welded or cool slowly. |
| 7 Cold weld puddle | A Loose welding cable connection. B Low primary voltage C Fault in power source | A Check all welding cable connections. B Contact supply authority. C Have an Accredited CIGWELD Service Provider to test then replace the faulty component. |
| 8 Arc does not have a crisp sound that short arc exhibits when the wirefeed speed and voltage are adjusted correctly. | The MIG torch has been connected to the wrong voltage polarity on the front panel. | Connect the MIG torch to the positive (+) welding terminal for solid wires and gas shielded flux cored wires. Refer to the electrode wire manufacturer for the correct polarity. |

Table 4-3: GMAW (MIG) Welding Problems

4.03 Stick (MMAW) Basic Welding Technique

Size of Electrode

The electrode size is determined by the thickness of metals being joined and can also be governed by the type of welding machine available. Small welding machines will only provide sufficient current (amperage) to run the smaller size electrodes.

For thin sections, it is necessary to use smaller electrodes otherwise the arc may burn holes through the job. A little practice will soon establish the most suitable electrode for a given application.

Storage of Electrodes

Always store electrodes in a dry place and in their original containers.

Electrode Polarity

Electrodes are generally connected to the ELECTRODE HOLDER with the Electrode Holder connected positive polarity. The WORK LEAD is connected negative polarity and is connected to the work piece. If in doubt consult the electrode data sheet or your nearest Accredited CIGWELD Distributor.

Effects of Arc Welding Various Materials

A. High tensile and alloy steels

The two most prominent effects of welding these steels are the formation of a hardened zone in the weld area, and, if suitable precautions are not taken, the occurrence in this zone of under-bead cracks may result. Hardened zone and under-bead cracks in the weld area may be reduced by using the correct electrodes, preheating, using higher current settings, using larger electrodes sizes, short runs for larger electrode deposits or tempering in a furnace.

Hydrogen controlled Electrodes must be used for this application. Use Ferrocrafter 61 or 16TXP for normal strength (500 MPa) steels, and Alloycraft range for higher strength steels.

B. Austenitic manganese steels

The effect on manganese steel of slow cooling from high temperatures is to embrittle it. For this reason it is absolutely essential to keep manganese steel cool during welding by quenching after each weld or skip welding to distribute the heat. Suitable Electrode types are Cobalarc Austex or Cobalarc Mangcraft.

C. Cast Iron

Most types of cast iron, except white iron, are weldable. White iron, because of its extreme brittleness, generally cracks when attempts are made to weld it. Trouble may also be experienced when welding white-heart malleable, due to the porosity caused by gas held in this type of iron. Suitable Electrode types are Castcraft 55 or Castcraft 100.

D. Copper and alloys

The most important factor is the high rate of heat conductivity of copper, making preheating of heavy sections necessary to give proper fusion of weld and base metal. Suitable Electrode types are Bronzecraft AC-DC electrodes.

Arc Welding Practice

The techniques used for arc welding are almost identical regardless of what types of metals are being joined. Naturally enough, different types of electrodes would be used for different metals as described in the preceding section.

Welding Position

The electrodes dealt with in this publication can be used in most positions, i.e. they are suitable for welding in flat, horizontal, vertical and overhead positions. Numerous applications call for welds to be made in positions intermediate between these. Some of the common types of welds are shown in Figures 4-15 through 4-22.




Figure 4-11: Flat Position, Down Hand Butt Weld




Figure 4-12: Flat Position, Gravity Fillet Weld




Figure 4-13: Horizontal Position, Butt Weld




Figure 4-14: Horizontal-Vertical (HV) Position




Figure 4-15: Vertical Position, Butt Weld




Figure 4-16: Vertical Position, Fillet Weld




Figure 4-17: Overhead Position, Butt Weld




Figure 4-18: Overhead Position, Fillet Weld


Joint Preparations

In many cases, it will be possible to weld steel sections without any special preparation. For heavier sections and for repair work on castings, etc., it will be necessary to cut or grind an angle between the pieces being joined to ensure proper penetration of the weld metal and to produce sound joints.


In general, surfaces being welded should be clean and free of rust, scale, dirt, grease, etc. Slag should be removed from oxy-cut surfaces. Typical joint designs are shown in Figure 4-19.

Open Square Butt Joint


Gap varies from
1.6mm (1/16") to 4.8mm (3/16")
depending on plate thickness




Single Vee Butt Joint




Single Vee Butt Joint




Double Vee Butt Joint




Lap Joint




Fillet Joint




Tee Joints (Fillet both sides of the joint)




Corner Weld




Edge Joint



Plug Weld



Plug Weld



Art # A-07695_AE

Figure 4-19: Typical Joint Designs for Arc Welding

Arc Welding Technique - A Word to Beginners

For those who have not yet done any welding, the simplest way to commence is to run beads on a piece of scrap plate. Use mild steel plate about 6.0mm thick and a 3.2mm electrode. Clean any paint, loose scale or grease off the plate and set it firmly on the work bench so that welding can be carried out in the downhand position. Make sure that the work clamp is making good electrical contact with the work, either directly or through the work table. For light gauge material, always clamp the work lead directly to the job, otherwise a poor circuit will probably result.

The Welder

Place yourself in a comfortable position before beginning to weld. Get a seat of suitable height and do as much work as possible sitting down. Don't hold your body tense. A taut attitude of mind and a tensed body will soon make you feel tired. Relax and you will find that the job becomes much easier. You can add much to your peace of mind by wearing a leather apron and gauntlets. You won't be worrying then about being burnt or sparks setting alight to your clothes.

Place the work so that the direction of welding is across, rather than to or from, your body. The electrode holder lead should be clear of any obstruction so that you can move your arm freely along as the electrode burns down. If the lead is slung over your shoulder, it allows greater freedom of movement and takes a lot of weight off your hand. Be sure the insulation on your cable and electrode holder is not faulty, otherwise you are risking an electric shock.

Striking the Arc

Practice this on a piece of scrap plate before going on to more exacting work. You may at first experience difficulty due to the tip of the electrode "sticking" to the work piece. This is caused by making too heavy a contact with the work and failing to withdraw the electrode quickly enough. A low amperage will accentuate it. This freezing-on of the tip may be overcome by scratching the electrode along the plate surface in the same way as a match is struck. As soon as the arc is established, maintain a 1.6mm to 3.2mm gap between the burning electrode end and the parent metal. Draw the electrode slowly along as it melts down.

Another difficulty you may meet is the tendency, after the arc is struck, to withdraw the electrode so far that the arc is broken again. A little practice will soon remedy both of these faults.




Figure 4-20: Striking an Arc

Arc Length

The securing of an arc length necessary to produce a neat weld soon becomes almost automatic. You will find that a long arc produces more heat. A very long arc produces a crackling or spluttering noise and the weld metal comes across in large, irregular blobs. The weld bead is flattened and spatter increases. A short arc is essential if a high quality weld is to be obtained although if it is too short there is the danger of it being blanketed by slag and the electrode tip being solidified in. If this should happen, give the electrode a quick twist back over the weld to detach it. Contact or "touch-weld" electrodes such as Ferrocrafter 21 do not stick in this way, and make welding much easier.

Rate of Travel

After the arc is struck, your next concern is to maintain it, and this requires moving the electrode tip towards the molten pool at the same rate as it is melting away. At the same time, the electrode has to move along the plate to form a bead. The electrode is directed at the weld pool at about 20° from the vertical. The rate of travel has to be adjusted so that a well-formed bead is produced.

If the travel is too fast, the bead will be narrow and strung out and may even be broken up into individual globules. If the travel is too slow, the weld metal piles up and the bead will be too large.

Making Welded Joints

Having attained some skill in the handling of an electrode, you will be ready to go on to make up welded joints.

A. Butt Welds

Set up two plates with their edges parallel, as shown in Figure 4-21, allowing 1.6mm to 2.4mm gap between them and tack weld at both ends. This is to prevent contraction stresses from the cooling weld metal pulling the plates out of alignment. Plates thicker than 6.0mm should have their mating edges bevelled to form a 70° to 90° included angle. This allows full penetration of the weld metal to the root. Using a 3.2mm Ferrocrafter 21 electrode at 100 amps, deposit a run of weld metal on the bottom of the joint.

Do not weave the electrode, but maintain a steady rate of travel along the joint sufficient to produce a well-formed bead. At first you may notice a tendency for undercut to form, but keeping the arc length short, the angle of the electrode at about 20° from vertical, and the rate of travel not too fast, will help eliminate this. The electrode needs to be moved along fast enough to prevent the slag pool from getting ahead of the arc. To complete the joint in thin plate, turn the job over, clean the slag out of the back and deposit a similar weld.




Figure 4-21: Butt Weld





Figure 4-22: Weld Build up Sequence

Heavy plate will require several runs to complete the joint. After completing the first run, chip the slag out and clean the weld with a wire brush. It is important to do this to prevent slag being trapped by the second run. Subsequent runs are then deposited using either a weave technique or single beads laid down in the sequence shown in Figure 4-22. The width of weave should not be more than three times the core wire diameter of the electrode. When the joint is completely filled, the back is either machined, ground or gouged out to remove slag which may be trapped in the root, and to prepare a suitable joint for depositing the backing run. If a backing bar is used, it is not usually necessary to remove this, since it serves a similar purpose to the backing run in securing proper fusion at the root of the weld.

B. Fillet Welds


These are welds of approximately triangular cross-section made by depositing metal in the corner of two faces meeting at right angles. Refer to Figure 4-14.

A piece of angle iron is a suitable specimen with which to begin, or two lengths of strip steel may be tacked together at right angles. Using a 3.2mm Ferrocrafter 21 electrode at 100 amps, position angle iron with one leg horizontal and the other vertical. This is known as a horizontal-vertical (HV) fillet. Strike the arc and immediately bring the electrode to a position perpendicular to the line of the fillet and about 45° from the vertical. Some electrodes require to be sloped about 20° away from the perpendicular position to prevent slag from running ahead of the weld. Refer to Figure 4-23. Do not attempt to build up much larger than 6.4mm width with a 3.2mm electrode, otherwise the weld metal tends to sag towards the base, and undercut forms on the vertical leg. Multi-runs can be made as shown in Figure 4-24. Weaving in HV fillet welds is undesirable.



Art # A-07699_AB

Figure 4-23: Electrode Position for HV Fillet Weld



Art # A-07700_AB

Figure 4-24: Multi-runs in HV Fillet Weld

C. Vertical Welds

1. Vertical Up

Tack weld a three feet length of angle iron to your work bench in an upright position. Use a 3.2mm Ferrocrafter 21 electrode and set the current at 100 amps. Make yourself comfortable on a seat in front of the job and strike the arc in the corner of the fillet. The electrode needs to be about 10° from the horizontal to enable a good bead to be deposited. Refer Figure 4-25. Use a short arc, and do not attempt to weave on the first run. When the first run has been completed de-slag the weld deposit and begin the second run at the bottom. This time a slight weaving motion is necessary to cover the first run and obtain good fusion at the edges. At the completion of each side motion, pause for a moment to allow weld metal to build up at the edges, otherwise undercut will form and too much metal will accumulate in the centre of the weld. Figure 4-26 illustrates multi-run technique and Figure 4-27 shows the effects of pausing at the edge of weave and of weaving too rapidly.

Art # A-07701




Figure 4-25: Single Run Vertical Fillet Weld

Art # A-07702






Figure 4-26: Multi Run Vertical Fillet Weld

CORRECT

Pause at edge of weave allows weld metal to build up, and eliminates undercut

INCORRECT

Note weld contour when insufficient pause at edge of weave

Art # A-07703

Figure 4-27: Examples of Vertical Fillet Welds

2. Vertical Down

The Ferrocrafter 21 electrode makes welding in this position particularly easy. Use a 3.2mm electrode at 100 amps. The tip of the electrode is held in light contact with the work and the speed of downward travel is regulated so that the tip of the electrode just keeps ahead of the slag. The electrode should point upwards at an angle of about 45°.

3. Overhead Welds

Apart from the rather awkward position necessary, overhead welding is not much more difficult than downhand welding. Set up a specimen for overhead welding by first tacking a length of angle iron at right angles to another piece of angle iron or a length of waste pipe. Then tack this to the work bench or hold in a vice so that the specimen is positioned in the overhead position as shown in the sketch. The electrode is held at 45° to the horizontal and tilted 10° in the line of travel (Figure 4-28). The tip of the electrode may be touched lightly on the metal, which helps to give a steady run. A weave technique is not advisable for overhead fillet welds. Use a 3.2mm Ferrocrafter 12XP electrode at 100 amps, and deposit the first run by simply drawing the electrode along at a steady rate. You will notice that the weld deposit is rather convex, due to the effect of gravity before the metal freezes.




Figure 4-28: Overhead Fillet Weld

Distortion

Distortion in some degree is present in all forms of welding. In many cases it is so small that it is barely perceptible, but in other cases allowance has to be made before welding commences for the distortion that will subsequently occur. The study of distortion is so complex that only a brief outline can be attempted here.

The Cause of Distortion

Distortion is caused by:

A. Contraction of Weld Metal:

Molten steel shrinks approximately 11 per cent in volume on cooling to room temperature. This means that a cube of molten metal would contract approximately 2.2 per cent in each of its three dimensions. In a welded joint, the metal becomes attached to the side of the joint and cannot contract freely. Therefore, cooling causes the weld metal to flow plastically, that is, the weld itself has to stretch if it is to overcome the effect of shrinking volume and still be attached to the edge of the joint. If the restraint is very great, as, for example, in a heavy section of plate, the weld metal may crack. Even in cases where the weld metal does not crack, there will still remain stresses "Locked-up" in the structure. If the joint material is relatively weak, for example, a butt joint in 2.0mm sheet, the contracting weld metal may cause the sheet to become distorted.

B. Expansion and Contraction of Parent Metal in the Fusion Zone:

While welding is proceeding, a relatively small volume of the adjacent plate material is heated to a very high temperature and attempts to expand in all directions. It is able to do this freely at right angles to the surface of the plate (i.e., "through the weld", but when it attempts to expand "across the weld" or "along the weld", it meets considerable resistance, and to fulfil the desire for continued expansion, it has to deform plastically, that is, the metal adjacent to the weld is at a high temperature and hence rather soft, and, by expanding, pushes against the cooler, harder metal further away, and tends to bulge (or is "upset"). When the weld area begins to cool, the "upset" metal attempts to contract as much as it expanded, but, because it has been "upset" it does not resume its former shape, and the contraction of the new shape exerts a strong pull on adjacent metal. Several things can then happen.

The metal in the weld area is stretched (plastic deformation), the job may be pulled out of shape by the powerful contraction stresses (distortion), or the weld may crack, in any case, there will remain "locked-up" stresses in the job. Figures 4-29 and 4-30 illustrate how distortion is created.




Figure 4-29: Parent Metal Expansion




Figure 4-30: Parent Metal Contraction

Overcoming Distortion Effects

There are several methods of minimizing distortion effects.

A. Peening

This is done by hammering the weld while it is still hot. The weld metal is flattened slightly and because of this the tensile stresses are reduced a little. The effect of peening is relatively shallow, and is not advisable on the last layer.

B. Distribution of Stresses

Distortion may be reduced by selecting a welding sequence which will distribute the stresses suitably so that they tend to cancel each other out. See Figures 4-30 through 4-33 for various weld sequences. Choice of a suitable weld sequence is probably the most effective method of overcoming distortion, although an unsuitable sequence may exaggerate it. Simultaneous welding of both sides of a joint by two welders is often successful in eliminating distortion.

C. Restraint of Parts

Forcible restraint of the components being welded is often used to prevent distortion. Jigs, positions, and tack welds are methods employed with this in view.

D. Presetting

It is possible in some cases to tell from past experience or to find by trial and error (or less frequently, to calculate) how much distortion will take place in a given welded structure. By correct pre-setting of the components to be welded, constructional stresses can be made to pull the parts into correct alignment. A simple example is shown in Figure 4-31.

E. Preheating

Suitable preheating of parts of the structure other than the area to be welded can be sometimes used to reduce distortion. Figure 4-32 shows a simple application. By removing the heating source from b and c as soon as welding is completed, the sections b and c will contract at a similar rate, thus reducing distortion.





Figure 4-31: Principle of Presetting



Dotted lines show effect if no preheat is used

Figure 4-32: Reduction of Distortion by Preheating




Figure 4-33: Examples of Distortion




Figure 4-34: Welding Sequence




Figure 4-35: Step back Sequence




Figure 4-36: Chain Intermittent Welding




Figure 4-37: Staggered Intermittent Welding


TRANSMIG 350i, 450i, 550i

Electrode Selection Chart (Further information on CIGWELD electrodes can be found at the website www.cigweld.com.au.)

| CIGWELD Electrode Selection Chart | | | | |
|-----------------------------------|-----------|-------------|----------|---|
| Description | Diameter | Pack | Part No. | Application |
| Satincraft 13 | 2.5mm | 1kg | 322135 | General purpose electrode suitable for all positional welding and galvanised steel. |
| | 2.5mm | 2.5kg | 612182 | |
| | 3.2mm | 1kg | 322136 | |
| | 3.2mm | 2.5kg | 612183 | |
| | 4.0mm | 5kg | 611184 | |
| Ferrocraft 12XP | 2.0mm | 1kg | 322128 | General purpose, Xtra performance electrode recommended for all positional (inc. Vertical down) welding of mild and galvanised steel. |
| | 2.0mm | 2.5kg | 612231 | |
| | 2.5mm | 1kg | 322129 | |
| | 2.5mm | 2.5kg | 612232 | |
| | 3.2mm | 1kg | 322138 | |
| | 3.2mm | 2.5kg | 612233 | |
| | 4.0mm | 5kg | 611234 | |
| WeldSkill GP | 2.0mm | 1 kg | WEG1020 | User-friendly GP electrode for welding thin section mild and galvanised steels. Excellent for vertical down fillet welding applications. |
| | 2.0mm | 2.5 kg | WEG2520 | |
| | 2.5mm | 1 kg | WEG1025 | |
| | 2.5mm | 2.5 kg | WEG2525 | |
| | 2.5mm | 5 kg | WEG5025 | |
| | 3.2mm | 1 kg | WEG1032 | |
| | 3.2mm | 2.5 kg | WEG2532 | |
| | 3.2mm | 5 kg | WEG5032 | |
| Ferrocraft 16 Twincoat | 2.5mm | 2.5kg | 612752 | Hydrogen Controlled type offering exceptional AC/DC performance in all welding positions. |
| | 2.5mm | 5 kg | 611752 | |
| | 3.2mm | 2.5kg | 612753 | |
| | 3.2mm | 5 kg | 611753 | |
| | 4.0mm | 5 kg | 611754 | |
| Satincrome 308L-17 | 2.5mm | 2.5 kg | 611602 | Stainless Steel type for 19Cr/10Ni stainless grades including 201, 202, 301, 302, 303, 304, 304L, 305, 308, etc |
| | 3.2mm | 2.5 kg | 611603 | |
| | 4.0mm | 2.5 kg | 611604 | |
| Satincrome 309Mo-17 | 2.5mm | 2.5 kg | 611692 | Stainless Steel type for 309 and 309L grades. It is also suitable for welding of dissimilar welding of other 300 series stainless steels. |
| | 3.2mm | 2.5 kg | 611693 | |
| | 4.0mm | 2.5 kg | 611694 | |
| Satincrome 316L-17 | 2.0mm | 2.5 kg | 611661 | Stainless Steel type for welding of matching Mo bearing grades, 316 and 316L. |
| | 2.5mm | 2.5 kg | 611662 | |
| | 3.2mm | 2.5 kg | 611663 | |
| | 2.5/3.2mm | Blisterpack | 322215 | |
| | 4.0mm | 2.5 kg | 611664 | |
| Weldall | 2.5mm | 2.5 kg | 611702 | High alloy stainless steel type for welding of unknown steels, repair of die or tool steels and for joining dissimilar steels. (Not recommended for cast iron). |
| | 3.2mm | 2.5 kg | 611703 | |
| | 2.5/3.2mm | Blisterpack | 322216 | |
| | 4.0mm | 2.5 kg | 611704 | |
| Castcraft 55 | 3.2mm | 2.5 kg | 611723 | For repair and maintenance welding of S.G. cast iron, meehanite and other cast irons. It produces high strength weld than Castcraft 100. |
| | 4.0mm | 2.5 kg | 611724 | |
| Castcraft 100 | 2.5mm | 2.5 kg | 611732 | Soft, Ductile Nickel type electrode for repair and maintenance welding of a wide range of cast irons. It has better "wetting" action than Castcraft 55. |
| | 3.2mm | 2.5 kg | 611733 | |
| | 2.5/3.2mm | Blisterpack | 322217 | |
| | 4.0mm | 2.5 kg | 611734 | |

Table 4-4: Cigweld Electrode Selection Chart

4.04 Stick (MMAW) Welding Troubleshooting

| FAULT | CAUSE | REMEDY |
|---|--|---|
| 1 Welding current varying | ARC FORCE control knob is set at a value that causes the welding current to vary excessively with the arc length. | Reduce the ARC FORCE control knob until welding current is reasonably constant while prohibiting the electrode from sticking to the work piece when you "dig" the electrode into the workpiece. |
| 2 A gap is left by failure of the weld metal to fill the root of the weld. | A Welding current too low B Electrode too large for joint. C Insufficient gap. | A Increase welding current. B Use smaller diameter electrode. C Allow wider gap. |
| 3 Non-metallic particles are trapped in the weld metal. | A Non-metallic particles may be trapped in undercut from previous run. B Joint preparation too restricted. C Irregular deposits allow slag to be trapped. D Lack of penetration with slag trapped beneath weld bead. E Rust or mill scale is preventing full fusion. F Wrong electrode for position in which welding is done. | A If a bad undercut is present clean slag bout and cover with a run from a smaller gauge electrode. B Allow for adequate penetration and room for cleaning out the slag. C If very bad, chip or grind out irregularities. D Use smaller electrode with sufficient current to give adequate penetration. Use suitable tools to remove all slag from comers. E Clean joint before welding. F Use electrodes designed for position in which welding is done, otherwise proper control of slag is difficult. |
|  <p>Figure 1-Example of insufficient gap or incorrect sequence</p> | | |
| 4 A groove has been formed in the base metal adjacent to the toe of a weld and has not been filled by the weld metal (undercut). | A Welding current is too high. B Welding arc is too long. C Angle of the electrode is incorrect. D Joint preparation does not allow correct electrode angle. E Electrode too large for joint. F Insufficient deposit time at edge of weave. G Power source is set for MIG (GMAW) welding. | A Reduce welding current. B Reduce the length of the welding arc. C Electrode should not be inclined less than 45° to the vertical face. D Allow more room in joint for manipulation of the electrode. E Use smaller gauge electrode. F Pause for a moment at edge of weave to allow weld metal buildup. G Set power source to STICK (MMAW) mode. |

| | | |
|--|---|---|
| <p>5 Portions of the weld run do not fuse to the surface of the metal or edge of the joint.</p> | <p>A Small electrodes used on heavy cold plate. B Welding current is too low. C Wrong electrode angle. D Travel speed of electrode is too high. E Scale or dirt on joint surface.</p> | <p>A Use larger electrodes and preheat the plate. B Increase welding current. C Adjust angle so the welding arc is directed more into the base metal. D Reduce travel speed of electrode. E Clean surface before welding.</p> |
| <div data-bbox="177 528 595 741"> </div> <p style="text-align: center;">Figure 2: Example of Lack of Fusion</p> | | |
| <p>6 Gas pockets or voids in weld metal (porosity)</p> | <p>A High levels of sulphur in steel. B Electrodes are damp. C Welding current is too high. D Surface impurities such as oil, grease, paint, etc. E Welding in a windy environment. F Electrode damaged ie flux coating incomplete.</p> | <p>A Use an electrode that is designed for high sulphur steels. B Dry electrodes before use. C Reduce welding current. D Clean joint before welding. E Shield the weld area from the wind. F Discard damaged electrodes and only use electrodes with a complete flux coating.</p> |
| <p>7 Crack occurring in weld metal soon after solidification commences</p> | <p>A Rigidity of joint. B Insufficient throat thickness. C Weld current is too high.</p> | <p>A Redesign to relieve weld joint of severe stresses or use crack resistance electrodes. B Travel slightly slower to allow greater build up in throat. C Decrease welding current.</p> |
| <div data-bbox="129 1496 853 1691"> </div> <p style="text-align: right;">Figure 3: Example of Slag Inclusion</p> | | |

Table 4-5: Welding Problems MMAW (Stick)

4.05 TIG (GTAW) Basic Welding Technique

Gas Tungsten Arc Welding (GTAW) or TIG (Tungsten Inert Gas) as it is commonly referred to, is a welding process in which fusion is produced by an electric arc that is established between a single tungsten (non-consumable) electrode and the work piece. Shielding is obtained from a welding grade shielding gas or welding grade shielding gas mixture which is generally Argon based. A filler metal may also be added manually in some circumstances depending on the welding application.




Figure 4-38: TIG Welding Application Shot

Tungsten Electrode Current Ranges

| Electrode Diameter | DC Current (Amps) |
|--------------------|-------------------|
| 0.040" (1.0mm) | 30-60 |
| 1/16" (1.6mm) | 60-115 |
| 3/32" (2.4mm) | 100-165 |
| 1/8" (3.2mm) | 135-200 |
| 5/32" (4.0mm) | 190-280 |
| 3/16" (4.8mm) | 250-340 |

Table 4-6: Current Ranges for Various Tungsten Electrode Sizes

Guide for Selecting Filler Wire Diameter

| Filler Wire Diameter | DC Current Range (Amps) |
|----------------------|-------------------------|
| 1/16" (1.6mm) | 20-90 |
| 3/32" (2.4mm) | 65-115 |
| 1/8" (3.2mm) | 100-165 |
| 3/16" (4.8mm) | 200-350 |

Table 4-7: Filler Wire Selection Guide

TRANSMIG 350i, 450i, 550i

Tungsten Electrode Types

| Electrode Type (Ground Finish) | Welding Application | Features | Colour Code |
|-----------------------------------|---|---|-------------|
| Thoriated 2% | DC welding of mild steel, stainless steel and copper | Excellent arc starting, Long life, High current carrying capacity | Red |
| Zirconated 1% | High quality AC welding of aluminium, magnesium and their alloys. | Self cleaning, Long life, Maintains balled end, High current carrying capacity. | White |
| Ceriated 2% | AC & DC welding of mild steel, stainless steel, copper, aluminium, magnesium and their alloys | Longer life, More stable arc, Easier starting, Wider current range, Narrower more concentrated arc. | Grey |

Table 4-8

NOTE

The Transmig 350i, 450i, 550i Inverter is not suited for AC Tig welding.

TIG Welding Filler Rods

| Comweld Rod | Aust Std | AWS Std | Part No. 1.6mm | Part No. 2.4mm | Part No. 3.2mm | Type/Application |
|----------------------------|-------------------------|-------------------------------|----------------------------|----------------------------|-------------------|--|
| LW1 LW1-6 Supersteel | R4 R6 R2 | ER70S-4 ER70S-6 ER70S-2 | 321411 321417 321370 | — — — | — — — | For mild-medium strength steels. Pipes, tubing, roll cages, etc. |
| CrMo1 CrMo2 | RB2 RB3 | ER80S-B2 ER90S-B3 | — — | 321379 321383 | — — | For welding of high strength Cr-Mo steels used at elevated temperatures. |
| 308L 309L 316L | R308L R309L R316L | ER308L ER309L ER316L | 321406 321403 321400 | 321407 321404 321401 | — — — | For stainless steels. Stainless pipes, tubing, architectural uses, etc. |

Table 4-9

| Base Metal Thickness | DC Current for Mild Steel | DC Current for Stainless Steel | Tungsten Electrode Diameter | Filler Rod Diameter (if required) | Argon Gas Flow Rate Litres/min | Joint Type |
|-----------------------------|----------------------------------|---------------------------------------|------------------------------------|--|---------------------------------------|------------------------|
| 0.040" 1.0mm | 35-45 40-50 | 20-30 25-35 | 0.040" 1.0mm | 1/16" 1.6mm | 5-7 | Butt/Corner Lap/Fillet |
| 0.045" 1.2mm | 45-55 50-60 | 30-45 35-50 | 0.040" 1.0mm | 1/16" 1.6mm | 5-7 | Butt/Corner Lap/Fillet |
| 1/16" 1.6mm | 60-70 70-90 | 40-60 50-70 | 1/16" 1.6mm | 1/16" 1.6mm | 7 | Butt/Corner Lap/Fillet |
| 1/8" 3.2mm | 80-100 90-115 | 65-85 90-110 | 1/16" 1.6mm | 3/32" 2.4mm | 7 | Butt/Corner Lap/Fillet |
| 3/16" 4.8mm | 115-135 140-165 | 100-125 125-150 | 3/32" 2.4mm | 1/8" 3.2mm | 10 | Butt/Corner Lap/Fillet |
| 1/4" 6.4mm | 160-175 170-200 | 135-160 160-180 | 1/8" 3.2mm | 5/32" 4.0mm | 10 | Butt/Corner Lap/Fillet |

Table 4-10

TIG Welding is generally regarded as a specialised process that requires operator competency. While many of the principles outlined in the previous Arc Welding section are applicable a comprehensive outline of the TIG Welding process is outside the scope of this Operating Manual. For further information please refer to www.cigweld.com or contact Cigweld.

4.06 TIG (GTAW) Welding Problems

| FAULT | CAUSE | REMEDY |
|---|--|---|
| 1 Excessive beard build up or poor penetration or poor fusion at edges of weld. | Welding current is too low | Increase weld current and/or faulty joint preparation. |
| 2 Weld bead too wide and flat or undercut at edges of weld or excessive burn through. | Welding current is too high | Decrease weld current. |
| 3 Weld bead too small or insufficient penetration or ripples in bead are widely spaced apart. | Travel speed too fast | Reduce travel speed. |
| 4 Weld bead too wide or excessive bead build up or excessive penetration in butt joint. | Travel speed too slow | Increase travel speed. |
| 5 Uneven leg length in fillet joint | Wrong placement of filler rod | Re-position filler rod. |
| 6 Electrode melts or oxidises when an arc is struck. | A Torch lead connected to positive welding terminal. B No gas flowing to welding region. C Torch is clogged with dust or dirt. D Gas hose is cut. E Gas passage contains impurities. F Gas regulator turned off. G Torch valve is turned off. H The electrode is too small for the welding current. I Power source is set for MIG welding. | A Connect torch lead to negative welding terminal. B Check the gas lines for kinks or breaks and gas cylinder contents. C Clean torch. D Replace gas hose. E Disconnect gas hose from the rear of Power Source then raise gas pressure and blow out impurities. F Turn on. G Turn on. H Increase electrode diameter or reduce the welding current. I Set Power Source to Lift TIG mode. |

| | | |
|-------------------------------------|--|--|
| 7 Dirty weld pool | <p>A Electrode contaminated by contact with work piece or filler rod material.</p> <p>B Work piece surface has foreign material on it.</p> <p>C Gas contaminated with air.</p> | <p>A Clean the electrode by grinding off the contaminates.</p> <p>B Clean surface.</p> <p>C Check gas lines for cuts and loose fitting or change gas cylinder.</p> |
| 8 Poor weld finish | Inadequate shielding gas. | Increase gas flow or check gas line for gas flow problems. |
| 9 Arc start is not smooth. | <p>A Tungsten electrode is too large for the welding current.</p> <p>B The wrong electrode is being used for the welding job.</p> <p>C Gas flow rate is too high.</p> <p>D Incorrect shielding gas is being used.</p> <p>E Poor work clamp connection to work piece.</p> | <p>A Select the right size electrode. Refer to Table 4-6 Cigweld Electrode Selection Chart.</p> <p>B Select the right electrode type. Refer to Table 4-8 Cigweld Electrode Selection Chart.</p> <p>C Select the right rate for the welding job. Refer to Table 4-10.</p> <p>D Select the right shielding gas.</p> <p>E Improve connection to work piece.</p> |
| 10 Arc flutters during TIG welding. | Tungsten electrode is too large for the welding current. | Select the right size electrode. Refer to Table 4-6 Cigweld Electrode Selection Chart. |

Table 4-11: GTAW (TIG) Welding Problems

SECTION 5: POWER SOURCE PROBLEMS AND ROUTINE SERVICE REQUIREMENTS

5.01 Power Source / Wirefeeder Problems

| FAULT | CAUSE | REMEDY |
|---|---|--|
| 1 Mains supply voltage is ON, power indicator is illuminated however unit will not commence welding when the torch trigger switch is depressed. | A Power source is not in the correct mode of operation. B Faulty torch trigger. | A Set the power source to the correct mode of operation with the process selection switch. B Repair or replace torch trigger switch/lead. |
| 2 Mains supply voltage is ON. Indicator light is not lit and welding arc cannot be established. | A Primary fuse is blown. B Broken connection in primary circuit. | A Replace primary fuse. B Have an Accredited CIGWELD Service Agent check primary circuit. |
| 3 Fault Indicator is illuminated and unit will not commence welding when the torch trigger switch is depressed. | Duty cycle of power source has been exceeded. | Leave the power source switched ON and allow it to cool. Note that fault indicator must be extinguished prior to commencement of welding. |
| 4 Wirefeeder will not feed wire in MIG mode. | A Electrode wire stuck in conduit liner or contact tip (burn-back jam). B Internal fault in power source | A Check for clogged / kinked MIG torch conduit liner or worn contact tip. Replace faulty components. B Have an Accredited CIGWELD Service Provider investigate the fault. |
| 5 Wire continues to feed when torch trigger released | A Trigger mode selection is in 4T (LATCH) mode(10 Pin socket only) B Torch trigger leads shorted | A Change to 2T (NORMAL) mode B Repair or replace Torch / trigger lead |
| 6 Wire feeds when the torch trigger switch is depressed but arc cannot be established. | Poor or no work lead contact. | Clean work clamp area and ensure good electrical contact. |
| 7 Inconsistent wire feed | A Worn or dirty contact tip B Worn feed roll. C Excessive back tension from wire reel hub. D Worn, kinked or dirty conduit liner | A Replace contact tip B Replace feed roll C Reduce brake tension on spool hub D Clean or replace conduit liner |
| 8 Wire does not feed when torch trigger depressed | Faulty trigger switch / lead | Repair or replace Torch / trigger lead |
| 9 TIG electrode melts when arc is struck. | TIG torch is connected to the (+) VE terminal. | Connect the TIG torch to the (-) VE terminal. |
| 10 Arc flutters during TIG welding. | Tungsten electrode is too large for the welding current. | Select the correct size of tungsten electrode. |

5.02 Routine Service and Calibration Requirements**WARNING**

There are extremely dangerous voltage and power levels present inside this Inverter Power Source. Do not attempt to open or repair unless you are an accredited CIGWELD Service Provider. Disconnect the Welding Power Source from the Mains Supply Voltage before disassembling.

Routine Inspection, Testing & Maintenance

The inspection and testing of the power source and associated accessories shall be carried out in accordance with Section 5 of AS 1674.2 - 2007: Safety in Welding and Allied Processes-Part 2 Electrical. This includes an insulation resistance test and an earthing test to ensure the integrity of the unit is compliant with Cigweld's original specifications.

If equipment is to be used in a hazardous location or environments with a high risk of electrocution as outlined in AS 1674.2 - 2007, then the above tests should be carried out prior to entering this location.

A. Testing Schedule

1. For transportable equipment, at least once every 3 months; and
2. For fixed equipment, at least once every 12 months.

The owners of the equipment shall keep a suitable record of the periodic tests and a system of tagging, including the date of the most recent inspection.

A transportable power source is deemed to be any equipment that is not permanently connected and fixed in the position in which it is operated.

B. Insulation Resistance

Minimum insulation resistance for in-service Cigweld Inverter Power Sources shall be measured at a voltage of 500V between the parts referred to in Table 6-1 below. Power sources that do not meet the insulation resistance requirements set out below shall be withdrawn from service and not returned until repairs have been performed such that the requirements outlined below are met.

| Components to be Tested | Minimum Insulation Resistance (M Ω) |
|---|---|
| Input circuit (including any connected control circuits) to welding circuit (including any connected control circuits) | 5 |
| All circuits to exposed conductive parts | 2.5 |
| Welding circuit (including any connected control circuits) to any auxiliary circuit which operates at a voltage exceeding extra low voltage | 10 |
| Welding circuit (including any connected control circuits) to any auxiliary circuit which operates at a voltage not exceeding extra low voltage | 1 |
| Separate welding circuit to separate welding circuit | 1 |

Table 5-2: Minimum Insulation Resistance Requirements: Cigweld Inverter Power Sources

C. Earthing

The resistance shall not exceed 1 Ω between any metal of a power source where such metal is required to be earthed, and -

1. The earth terminal of a fixed power source; or
2. The earth terminal of the associated plug of a transportable power source

Note that due to the dangers of stray output currents damaging fixed wiring, the integrity of fixed wiring supplying Cigweld welding power sources should be inspected by a licensed electrical worker in accordance with the requirements below -

1. For outlets/wiring and associated accessories supplying transportable equipment - at least once every 3 months; and
2. For outlets/wiring and associated accessories supplying fixed equipment - at least once every 12 months.

D. Voltage Reduction Device (VRD)

Units fitted with VRD's, shall have the periodic tests outlined in Table 6-2 below conducted by an accredited CIGWELD service provider. Testing shall be conducted at intervals as outlined below -

1. For transportable equipment, at least once every 3 months; and
2. For fixed equipment, at least once every 12 months.

| Description | Required Parameters |
|--------------------------|---|
| VRD Open Circuit Voltage | Less than 35V; at nominal input voltage |
| VRD Turn OFF Resistance | Less than 200 ohms |
| VRD Turn ON Time | Less than 0.3 seconds |

Table 5-3: VRD Periodic Tests

E. General Maintenance Checks

Welding equipment should be regularly checked by an accredited Cigweld Service Provider to ensure that:

1. Flexible cord is of the multi-core tough rubber or plastic sheathed type of adequate rating, correctly connected and in good condition.
2. Welding terminals are in suitable condition and are shrouded to prevent inadvertent contact or short circuit.
3. The Welding System is clean internally, especially from metal filing, slag, and loose material.

F. Accessories

Accessory equipment, including output leads, electrode holders, torches, wire feeders and the like shall be inspected at least monthly by a competent person to ensure that the equipment is in a safe and serviceable condition. All unsafe accessories shall not be used.

G. Repairs

If any parts are damaged for any reason, it is recommended that replacement be performed by an accredited Cigweld Service Provider.

Power Source Calibration

A. Schedule

Output testing of all Cigweld Inverter Power Sources and applicable accessories shall be conducted at regular intervals to ensure they fall within specified levels. Calibration intervals shall be as outlined below -

1. For transportable equipment, at least once every 3 months; and
2. For fixed equipment, at least once every 12 months.

If equipment is to be used in a hazardous location or environments with a high risk of electrocution as outlined in AS 1674.2 - 2007, then the above tests should be carried out prior to entering this location.

B. Calibration Requirements

Where applicable, the tests outlined in Table 6-3 below shall be conducted by an accredited CIGWELD service agent.

| Testing Requirements |
|---|
| Output current (A) to be checked to ensure it falls within applicable Cigweld power source specifications |
| Output Voltage (V) to be checked to ensure it falls within applicable Cigweld power source specifications |
| Motor Speed (RPM) of wire drive motors to be checked to ensure it falls within required Cigweld power source / wire feeder specifications |
| Accuracy of digital meters to be checked to ensure it falls within applicable Cigweld power source specifications |

Table 5-4: Calibration Parameters

Periodic calibration of other parameters such as timing functions are not required unless a specific fault has been identified.

C. Calibration Equipment

All equipment used for Power Source calibration shall be in proper working condition and be suitable for conducting the measurement in question. Only test equipment with valid calibration certificates (NATA certified laboratories) shall be utilized.

5.03 Cleaning the Welding Power Source



WARNING

There are dangerous voltage and power levels present inside this product. Do not attempt to open or repair unless you are a qualified electrical tradesperson. Disconnect the Welding Power Source from the Mains Supply Voltage before disassembling.

To clean the Welding Power Source, open the enclosure and use a vacuum cleaner to remove any accumulated dirt, metal filings, slag and loose material. Keep the shunt and lead screw surfaces clean as accumulated foreign material may reduce the welders output welding current.

5.04 Cleaning the Feed Rolls

Clean the grooves in the drive rolls frequently. This can be done by using a small wire brush. Also wipe off, or clean the grooves on the upper feed roll. After cleaning, tighten the feed roll retaining knobs.



CAUTION

Do not use compressed air to clean the Welding Power Source. Compressed air can force metal particles to lodge between live electrical parts and earthed metal parts within the Welding Power Source. This may result in arcing between this parts and their eventual failure.

SECTION 6: KEY SPARE PARTS

6.01 Power Source





Figure 6-1

| Item | Part Number | Description |
|------|-------------|--|
| 1 | W7005202 | PCB, main control 550i |
| 1 | W7005208 | PCB, main control 450i |
| 1 | W7005209 | PCB, main control 350i |
| 2 | W7005210 | Filter, EMC (all models) |
| 3 | W7005206 | PCB, display (all models) |
| 4 | W7005205 | PCB, Filter EMC (all models) |
| 5 | W7005207 | PCB, diode snubber (all models) |
| 6 | W7005211 | Auxiliary transformer T2 (all models) |
| 7 | W7005212 | Auxiliary transformer T3 (all models) |
| 8 | W7005213 | Capacitor, Silver (all models) |
| 9 | W7005214 | Diode, Welding (all models) |
| 10 | W7005215 | Inverter transformer 550i |
| 10 | W7005216 | Inverter transformer 450i |
| 10 | W7005217 | Inverter transformer 350i Power Source Part No. W1005352 |
| 10 | W7005230 | Inverter transformer 350i Power Source Part No. W1005359 |
| 11 | W7005218 | Inductor (all models) |

Table 6-1 Key Spare Parts




A-10643_AB

| Item | Part Number | Description |
|------|-------------|---|
| 12 | W7005219 | Sensor, Hall Effect (all models) |
| 13 | W7005201 | PCB, IGBT driver (all models) |
| 14 | W7005203 | PCB, IGBT snubber (all models) except 350i Power Source Part No. W1005359 |
| 14 | W7005228 | PCB, IGBT snubber 350i Power Source Part No. W1005359 |
| 15 | W7005204 | PCB, current transformer (all models)except 350i Power Source Part No. W1005359 |
| 15 | W7005229 | PCB, current transformer 350i Power Source Part No. W1005359 |
| 16 | W7005220 | Relay, Solid State (all models) |
| 17 | W7005221 | Fan, 230V Transmig (all models) |
| 18 | W7005222 | IGBT (all models) |
| 19 | W7005223 | Input rectifier bridge (all models) |
| 20 | W7005224 | Capacitor, Poly, 20uF (all models) |
| 21 | W7005225 | Capacitor, Poly, 5uF (all models) |
| 22 | W7005226 | Welding Current DINSE Terminal (all models) |
| 23 | W7005227 | Varistor 550V 25Dia |

Table 6-2 Key Spare Parts

SECTION 7: VOLT/AMPERE CURVES

7.01 Volt/Amp Curves




A-10644

Table 7-1 Volt/Amp Curves

SECTION 8: CIRCUIT DIAGRAM

8.01 CIRCUIT DIAGRAM



A-10647_AC

CIGWELD - LIMITED WARRANTY TERMS

LIMITED WARRANTY: CIGWELD Pty Ltd, A Victor Technologies Company, hereafter, "CIGWELD" warrants to customers of its authorized distributors hereafter "Purchaser" that its products will be free of defects in workmanship or material. Should any failure to conform to this warranty appear within the time period applicable to the CIGWELD products as stated below, CIGWELD shall, upon notification thereof and substantiation that the product has been stored, installed, operated, and maintained in accordance with CIGWELD's specifications, instructions, recommendations and recognized standard industry practice, and not subject to misuse, repair, neglect, alteration, or accident, correct such defects by suitable repair or replacement, at CIGWELD's sole option, of any components or parts of the product determined by CIGWELD to be defective.

CIGWELD MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED. THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHERS, INCLUDING, BUT NOT LIMITED TO ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

LIMITATION OF LIABILITY: CIGWELD SHALL NOT UNDER ANY CIRCUMSTANCES BE LIABLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, SUCH AS, BUT NOT LIMITED TO, LOST PROFITS AND BUSINESS INTERRUPTION. The remedies of the Purchaser set forth herein are exclusive and the liability of CIGWELD with respect to any contract, or anything done in connection therewith such as the performance or breach thereof, or from the manufacture, sale, delivery, resale, or use of any goods covered by or furnished by CIGWELD whether arising out of contract, negligence, strict tort, or under any warranty, or otherwise, shall not, except as expressly provided herein, exceed the price of the goods upon which such liability is based. No employee, agent, or representative of CIGWELD is authorized to change this warranty in any way or grant any other warranty.

PURCHASER'S RIGHTS UNDER THIS WARRANTY ARE VOID IF REPLACEMENT PARTS OR ACCESSORIES ARE USED WHICH IN CIGWELD'S SOLE JUDGEMENT MAY IMPAIR THE SAFETY OR PERFORMANCE OF ANY CIGWELD PRODUCT. PURCHASER'S RIGHTS UNDER THIS WARRANTY ARE VOID IF THE PRODUCT IS SOLD TO PURCHASER BY NON-AUTHORIZED PERSONS.

The warranty is effective for the time stated below beginning on the date that the authorized distributor delivers the products to the Purchaser. Notwithstanding the foregoing, in no event shall the warranty period extend more than the time stated plus one year from the date CIGWELD delivered the product to the authorized distributor.

TERMS OF WARRANTY – JULY 2011

1. The Trade Practices Act 1974 (Commonwealth) and similar State Territory legislation relating to the supply of goods and services, protects consumers' interests by ensuring that consumers are entitled in certain situations to the benefit of various conditions, warranties, guarantees, rights and remedies (including warranties as to merchantability and fitness for purpose) associated with the supply of goods and services. A consumer should seek legal advice as to the nature and extent of these protected interests. In some circumstances, the supplier of goods and services may legally stipulate that the said conditions, warranties, guarantees, rights and remedies are limited or entirely excluded. The warranties set out in Clause 2 shall be additional to any nonexcludable warranties to which the Customer may be entitled pursuant to any statute.
2. Subject to Clause 3. CIGWELD gives the following warranties to the Customer:

Insofar as they are manufactured or imported by CIGWELD, goods will upon delivery be of merchantable quality and reasonably fit for the purpose for which they are supplied by CIGWELD.

CIGWELD will repair or, at its option, replace those of the goods which, upon examination, are found by CIGWELD to be defective in workmanship and/or materials.

CIGWELD reserves the right to request documented evidence of date of purchase.
3. The Warranty in Clause 2;

Is conditional upon:

The Customer notifying CIGWELD or our Accredited Distributor in writing of its claim within seven (7) days of becoming aware of the basis thereof, and at its own expense returning the goods which are the subject of the claim to CIGWELD or nominated Accredited Distributor/Accredited Service Provider. The goods being used in accordance with the Manufacturer's Operating Manuals, and under competent supervision.

Does not apply to:

Obsolete goods sold at auction, second-hand goods and prototype goods.

Breakdown or malfunction caused by accident, misuse or normal wear and tear.

Repairs or replacement made other than by CIGWELD or Accredited Service Providers, unless by prior arrangement with CIGWELD.

Replacement parts or accessories which may affect product safety or performance and which are not manufactured, distributed or approved by CIGWELD.
4. CIGWELD declares that, to the extent permitted by law, it hereby limits its liability in respect of the supply of goods which are not of a kind ordinarily acquired for personal, domestic or household use or consumption to any one or more of the following (the choice of which shall be at the option of CIGWELD).
- The replacement of the goods or the supply of equivalent goods.

The repair of goods.

The payment of cost of replacing the goods or acquiring equivalent goods.

The payment of the cost of having goods repaired.
5. Except as provided in Clauses 2 to 4 above, to the extent permitted by statute, CIGWELD hereby excludes all liability for any loss, damage, death or injury of any kind whatsoever occasioned to the Customer in respect of the supply of goods including direct, indirect, consequential or incidental loss, damage or injury of any kind.

WARRANTY SCHEDULE – JULY 2011

These warranty periods relate to the warranty conditions in clause 2. All warranty periods are from date of sale from the Accredited Distributor of the equipment. Notwithstanding the foregoing, in no event shall the warranty period extend more than the time stated plus one year from the date CIGWELD delivered the product to the Accredited Distributor. Unless otherwise stated the warranty period includes parts and labour. CIGWELD reserves the right to request documented evidence of date of purchase.

| TRANSMIG 350i, 450i, 550i POWER SOURCE | WARRANTY PERIOD | LABOUR |
|---|------------------------|---------------|
| Original main power magnetics. | 3 Years | 2 Years |
| Original main power rectifiers, printed circuit boards and power switch semiconductors. | 2 Years | 2 Years |
| All other circuits and components including, but not limited to, relays, switches, contactors, solenoids, fans and electric motors. | 1 Year | 1 Year |
| ACCESSORIES | WARRANTY PERIOD | |
| MIG torch, electrode holder lead and work lead. | 3 Months | |
| MIG torch consumable items. | NIL | |
| Gas regulator/flowmeter (excluding seat assembly, pressure gauges, elastomer seals and "O" rings). | 1 Year | |
| Regulator seat assemblies and pressure gauges. | 6 Months | |
| Elastomer seals and "O" rings used in the equipment. | 3 Months | |

Please note that the information detailed in this statement supersedes any prior published data produced by CIGWELD.

Note: For Wirefeeder Warranty information refer to the relevant Wirefeeder Operating Manual.



GLOBAL CUSTOMER SERVICE CONTACT INFORMATION

Cigweld, Australia

71 Gower Street
Preston, Victoria
Australia, 3072
Telephone: 61-3-9474-7400
Fax: 61-3-9474-7391
Email: cigweldsales@cigweld.com.au

Victor Technologies USA

2800 Airport Road
Denton, Tx 76207 USA
Telephone: (940) 566-2000
800-426-1888
Fax: 800-535-0557
Email: sales@thermalarc.com

Victor Technologies Canada

2070 Wyecroft Road
Oakville, Ontario
Canada, L6L5V6
Telephone: (905)-827-1111
Fax: 905-827-3648

Victor Technologies Europe

Europe Building
Chorley North Industrial Park
Chorley, Lancashire
England, PR6 7Bx
Telephone: 44-1257-261755
Fax: 44-1257-224800

PT. Victor Technologies Utama Indonesia

Jl. Angsana II Blok AE No. 28
Delta Silicon I, Cikarang - Sukaresmi
Bekasi, 17550
Indonesia
Tel: +62 21 8990 6095
Fax: +62 21 8990 6096 / 1867
<http://www.Victor Technologies.com>

Victor Technologies, China

No 100 Lao Hongjing Rd
Minhang District
Shanghai, PR, 200235
Telephone: 86-21-64072626
Fax: 86-21-64483032

Victor Technologies Asia Sdn Bhd

Lot 151, Jalan Industri 3/5A
Rawang Integrated Industrial Park - Jln Batu Arang
48000 Rawang Selangor Darul Ehsan
West Malaysia
Telephone: 603+ 6092 2988
Fax : 603+ 6092 1085

Victor Technologies Italy

OCIM, S.r.L.
Via Benaco, 3
20098 S. Giuliano
Milan, Italy
Tel: (39) 02-98 80320
Fax: (39) 02-98 281773

Victor Technologies International

2070 Wyecroft Road
Oakville, Ontario
Canada, L6L5V6
Telephone: (905)-827-9777
Fax: 905-827-9797

Asia Pacific Regional Headquarters

71 Gower Street

Preston, Victoria, Australia, 3072

Telephone: +61 3 9474 7400

FAX: +61 3 9474 7391

Email: enquiries@cigweld.com.au

www.cigweld.com.au

CIGWELD